

PT Value / Paramount Series Adjustments



- 1** – Lifting the Pneumatic handle while seated on the chair allows the seat to descend to the desired height. While not seated on the chair and lifting the Pneumatic handle will permit the seat height to rise.
- 2** – While seated in the chair, lift up on the Back Tilting lever to release the back and adjust the angle of the chair back. When the desired proper back angle is determined, push down on the lever to lock into that position.
- 3** – Back Height is adjustable by placing both hands at the bottom of the chair back and easily lifting upwards. The back will ratchet upward one click at a time. To lower the back to its lowest point, raise the back all the way upwards for it to descend to its lowest point, and then lift upwards again to ratchet to the desired position.
- 4** – Lifting up on the Tilting Seat lever unlocks the seat for articulating backwards or forwards. Leaving the lever in the up / unlocked position permits to chair to always be free for tilting operation. Pushing the lever downward will lock the chair in any desired position.
- 5** – Sliding Seat provides depth of the seat in relation to the back of the chair. While seated, lift up on the lever to lengthen or shorten the seat depth to provide adequate support under the thighs.
- 7** – The Tension Knob properly balances the backward tilting resistance to the individual user’s body weight. Turning the knob underneath the seat to the left (counter-clockwise) loosens the resistance, while turning the knob to the right (clockwise) will increase the resistance.
- 8** – Lower Lumbar support can be adjusted by turning the knob on the right side of the chair back. Turning the knob to the right (clockwise) will expand and increase the lumbar support, while turning the knob to the left (counter-clockwise) will decrease the lumbar support.
- 9** – Forward Tilting permits the chair to be in a frontward angle for ergonomic – task operation. While seated, lift up on the Tilting Seat lever (#4) to unlock tilting function. Slightly lean backwards to take the weight off the front edge of the seat, and then “roll” the Forward Tilting handle “downward” to allow the chair to articulate at a forward incline. The seat may be locked at any forward position by pushing the Tilting Seat lever (#4) downward.

Adjustment functions may be viewed for the PT Value Line or the Paramount Collection by model # at