




20-JUL-2020
RD360.dgn




METHOD "A"




METHOD "B"



METHOD "C"




PLAN
SQUARE CUT



PLAN
CIRCULAR CUT

GENERAL NOTES FOR ALL DETAILS ON THIS SHEET:

1. Cover manhole with building paper and const. asph. conc. base course and wearing courses.
2. Saw cut square or circular excavation around manhole 12" min. from manhole frame.
3. Raise manhole cover and frame to finish grade by installing conc. manhole adjustment rings and leveling mortar, as shown.
4. Backfill with early strength Portland Cement Concrete. All concrete shall be commercial grade concrete.
5. Protect from traffic loading until conc. has cured to 3000 psi.
6. Apply tack coat to edges of existing pavement before installing patch.
7. Finish joint with asphalt seal and sand.
8. See Std. Dwg. RD336 for manhole steps details.
9. See appropriate manhole standard drawings for details not shown.
10. Use epoxy for synthetic grade rings.
11. See Std. Dwg. RD336 for tracer wire details.
12. See Std. Dwg. RD356 for manhole covers and frames.



ALTERNATE "A"

The selection and use of this Standard Drawing, while designed in accordance with generally accepted engineering principles and practices, is the sole responsibility of the user and should not be used without first consulting a Registered Professional Engineer.

All materials shall be in accordance with the current Oregon Standard Specifications.

OREGON STANDARD DRAWINGS

MANHOLE FRAME
ADJUSTMENT

2024

DATE	REVISION	DESCRIPTION
CALC. BOOK NO.	N/A	SDR DATE

21-JUL-2015 RD360

Effective Date: June 1, 2026 – November 30, 2026