

OREGON SPECIAL WIND REGIONS

Use the ATC hazards by location webtool, provided by the Applied Technology Council (ATC), for site-specific wind load determination. Follow these steps to help you through the process.

Example: Mapleton High School

1. Visit the website

Hazards.atcouncil.org

2. Enter the address (or coordinates if there is no address)

**10868 E Mapleton Rd.,
 Mapleton, OR 97453**

3. Select the "Wind" tab

4. Select "Search"

5. A dynamic map of the area will open, and you will be prompted to:

"Select a dataset to view contours."

- ASCE-16 version
- Risk Category II

6. A shaded overlay will appear over the special wind regions

