

DEQ's Hazardous Waste Program Annual Hazardous Waste Report Management Method Code Group



State of Oregon
Department of
Environmental
Quality

Management Method codes describe the type of hazardous waste management system used to treat, recover, or dispose of a hazardous waste. Select the final substantive method used. Review the groups and pick the appropriate code for use on the Generation and Management (GM) forms.

Reclamation and Recovery	
H010	Metals recovery including retorting, smelting, chemical, etc.
H020	Solvents recovery (distillation, extraction, etc.)
H039	Other recovery or reclamation for reuse including acid regeneration, organics recovery, etc. (specify in comments)
H050	Energy recovery at this site - used as fuel (includes on-site fuel blending before energy recovery; report only this code)
H061	Fuel blending prior to energy recovery at another site (waste generated either on site or received from off-site)
Destruction or Treatment Prior to Disposal at Another Site	
H040	Incineration - thermal destruction other than use as a fuel (includes any preparation prior to burning)
H070	Chemical treatment (reduction/destruction/oxidation/precipitation)
H081	Biological treatment with or without precipitation (includes any preparation or final processes for consolidation or residuals)
H100	Physical treatment (adsorption/absorption/separation/stripping/dewatering)
H110	Stabilization prior to land disposal at another site (encapsulation/stabilization/fixation)
H120	Combination of chemical, biological, and/or physical treatment
H121	Neutralization only (no other treatment)
H122	Evaporation (as the major component of treatment; not reportable as H070, H081, H110 or H120)
H129	Other treatment that does not include onsite disposal (specify in comments)
Disposal	
H130	Surface Impoundment that will be closed as a landfill (with prior treatment and/or stabilization)
H131	Land treatment or application (to include any prior treatment and/or stabilization)
H132	Landfill (with prior treatment and/or stabilization)
H134	Deep well or underground injection (with or without treatment; this waste was counted as hazardous waste)
H135	Discharge to sewer/POTW or NPDES (with prior storage - with or without treatment)
H136	Direct discharge (POTW or NPDES) without prior accumulation or storage
H138	Re-infiltration of treated groundwater
Transfer Off-site	
H141	The site receiving this waste stored/bulked and transferred the waste with no treatment or recovery (H010-H129), fuel blending (H061), or disposal (H131-H135) at that receiving site. This code is for use on the WR Form only. Do not use this code on the Generation & Management (GM) Form. Only use on the Waste Received (WR) form by Treatment, Storage, Disposal (TSD) facilities.

Hazardous Waste
700 NE Multnomah St.,
Suite 600
Portland, OR 97232-4100
Phone: 503-229-6968
800-452-4011
Fax: 503-229-5675
Contact: Mary Fritzmann
www.oregon.gov/DEQ/