

PLUGGING RECORD

Every operator of any geothermal well or prospect well shall file this form with the Department of Mineral Industries setting forth in detail the method used in plugging or abandoning any geothermal well, or within sixty (60) days for prospect wells.

Sec. 2009 of the regulations adopted pursuant to ORS 522 (Chapter 776, OL 1971)

Operator U.S. Geological Survey, assigned to: Field Mt. Hood  
Wy'East Exploration and Dev. Pool Pucci  
County Clackamas

ADDRESS ALL CORRESPONDENCE CONCERNING THIS FORM TO OPERATOR AT:

Street 852 N.W. Albemarle Terr. City Portland State OR 97210 Zip  
Lease Name Pucci Chairlift Well No. 1 Sec. 7 T. 3S R. 9E  
Date well was plugged August 29 19 85

Was the well filled with cement ~~fluid~~, according to regulations of the Board of the State of Oregon Department of Geology and Mineral Industries? Yes

How was the ~~fluid~~ cement applied? drill pipe to bottom Were plugs used? yes If so, show all shoulders left for casing, depth of each, and size of casing, size and kind of plugs used, and depths placed. Also amount of cement used.

Packer set at 1200', 260 sacks of cement applied through tubing from bottom ;up. Applied 30 sacks of ready-mix from top , filled annulus. Plug tagged at 20'. Filled to surface with ready-mix.

Richard G. Bowen  
Operator

Richard G. Bowen, President  
AFFIDAVIT

RECEIVED - PTLD

SEP 25 1985

DEPT. OF GEOLOGY  
& MINERAL INDUSTRIES

State of Oregon  
County of Multnomah

Before me, the undersigned authority, on this day personally appeared known to me to be the person whose name is subscribed to the above instrument, who being by me duly sworn on oath states that he is authorized to make this report and has knowledge of the facts stated herein and that said report is true and correct.

Subscribed and sworn to before me this 25<sup>th</sup> day of September, 19 85.

Mary In the

Notary public in and for Oregon

My commission expires 9-1-86