Form 6-54

4-15-83

4-19-83

STATE OF CRESCN DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES Portland 1, Oregon 1069 State Office Building

HISTORY OF OIL OR GAS WELL

(Submit in duplicate)

In complia	ance with rules and regulations adop	ted pursuant	to O	RS 520.	095	(Chapt	ter 667 OL 19	53)	
-				Field					
Well No.	Columbia County 14-33	, Sec.	33	,	т.	7N	R.	5W	W.B. & M.

Signed Ida Ilaina Title Field Operations Supervisor (President, Secretary or Agent)

Date April 20, 1983

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date 4- 8-83 Spudded well and drilling 12 1/4" hole to 542' Run 12 jts 8 5/8" casing to a measured depth of 535.66' Pumped 293 sxs class "G" cement 4- 9-83 Test BOP's with Dennis Olmstead and drilling cement 4-10-83 Drilling 954' Drilling 1472' 4-11-83 4-12-83 4-13-83 Drilling 1950' Drilling 2417' 4-14-83

TD well at 3105' 4-16-83 4-17-83 Logging with Welex and waiting on orders

Drilling 2798'

Abandon well, bottom plug set from 2950-2750 with 74 sxs class "G" cement. Top plug was set from 640' - 440' with 81 sxs class "G" cement. Go in hole and tag plug at 450' with Dennis Olmstead witnessing. 4-18-83