

Daily well History - Interim

Instructions: This form is used during drilling or workover operations. If testing, coring, or perforating, show formation name in describing work performed. Number all stem tests sequentially. Attach description of all cores. Work performed by Producing Section will be reported on "Interim" sheets until final completion. Report on a representative test on "Final" form. Submit "Interim" sheets when filed but not less frequently than every 30 days, or 12, on Wednesday of the week in which drilling is set. Submit weekly for workovers and to be in setting of casing until completion.

District WESTERN	County or Parish COLUMBIA	State OR
Field MIST	Lease or Unit CAVENHAM ENERGY RESOURCES	Well No. 23-16-64

Date and depth as of 8:00 a.m. Complete record for each day while drilling or workover in progress

4-1/2
10-06-88

TD: 1775' (0') RR

RD Atlas. TIH w/ OEDP to 920'. Mix and pump 100 sx Cl "G" + 3% CaCl₂ @ 15.8 ppg CIP @ 1350 hrs 10/5/88. WOC. Tag TOC @ 720' - DOGMI witnessed. POOH. ND BOPE. Cut off 9-5/8" casing. Lay 15 sx Cl "G" + 3% CaCl₂ surface plug. Weld on abandonment plate. Release rig @ 0000 hrs 10/6/88.

The above is correct

Signature <i>J. D. Stotts</i>	Date <i>3/3/89</i>	Title DISTRICT DRILLING ENGINEER
----------------------------------	-----------------------	--

For form and distribution see District Section 10. District Engineer

Number all daily well history forms consecutively, as they are prepared for each well.

Page No.

343