

HISTORY OF OIL OR GAS WELL  
(Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator American Quasar Petroleum Co. Field Wildcat  
Well No. Crown Zellerbach #15-14 , Sec. 15 , T. 6N R. 4W W.B. & M.

Signed *John F. Sindelar*  
John F. Sindelar  
Title Division Drlg. Supt.  
~~-(President, Secretary or Agent)~~

Date October 23, 1979

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date

(See attached chronological report from 10/11-23/79.)