STATE OF OREGON
DEPA MENT OF GEOLOGY AND MINERAL INC RIES
1069 ce Office Building Portland 1, Oregon

HISTORY OF OIL OR GAS WELL (Submit in duplicate)

32

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator Reichhold Energy Corporation

Field Mist

Well No. Longview Fibre 41-32

, Sec.

, T. 7N

_ 5W

W. B. & M.

Date 11-19-81

Signed Turnelly B. Welliamser

Title Drilling Superintendent
(President, Secretary or Agent)

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

10-9-81

Date

- Drlg., 9 7/8"surface hole depth 465'
- Ran 7" casing to 440', cemented same with 200 sx. class G cement w/ 3% cacl., bumped plug at 11:30 A.M.
- Waiting on cement, testing Bop's in preparation to drillout of shoe. Commenced drlg., depth 1345'.
- 10-12-81 Drlg., depth 2175'.
- 10-13-81 Drlg., depth 2487.
- 10-14-81 Logging with Welex.
- 10-15-81 Plugging well with Haliburton.
- 10-16-81 Tagged top plug at 150'. Rigging down.
- 10-17-81 Released rig.