

MICRO MOBILITY FIRE WORKSHEET

☐ Life Safety

- Wear full PPE.
- Rescue/Check for victims.
- Evacuate / Shelter In Place.

☐ Incident Stabilization

- **If outdoors**
 - Allow micro mobility to burn to completion
 - Prevent propagation to other devices/battery packs
 - Request HIRT to assist with battery stabilization, mitigation, overpacking, and disposal.
- **If indoors/structure fire considerations**
 - Attack the residential fire like normal
 - If in an enclosed space, explosive atmospheres are possible.
 - Remove the involved micro mobility device from structure, if possible.
 - **Move ALL Lithium-Ion Batteries (cells, batteries, etc.) and devices to a safe location, away from firefighting operations PRIOR to initiating overhaul**
 - During fire operations uninvolved batteries and devices may ignite behind you, underneath you, or all around you.
 - Use shovel with wooden handle (DO NOT USE HANDS OR POCKETS)
 - Outside is preferred
 - If not possible, consider a bathroom, bathtub, sink or metal bucket and fill with water.
 - Ensure ventilation (i.e. hydraulic) is provided for enclosed areas such as small bathrooms.
- **Overhaul**
 - Wear full PPE including donned SCBA!
 - Request HIRT to assist with battery stabilization, mitigation, overpacking, disposal, and civilian guidance.
 - Assist HIRT in removing all batteries from structure.
 - Provide protection line during HIRT overpacking procedures.