

EN...FIN - AUGUST 7, 199
HADRASNAVA CC 32-28-75
PERT 2666 - 2672

Time (minutes)	Choke	Orifice	Casing Pr.	Tubing Pr.	Orifice Pr.	Flow Rate (MMCF)
	Shot @ 12:35 pm. Rig slow to down stage					
	Two Swab Runs to 1:45 pm					
	Two more Swab Runs to 2:00 pm					
	Well weak flow to 2:30. Shut-in					
	Slow pressure build up. 280 psi @ 3:05 pm					
	Drop Soap Sticks down hole @ 3:05 pm					
	Pressure @ 320 psi @ 3:30 pm					
	Open well up - blow soap water and gas to 3:45 pm. Weak flow.					
3:45 pm	16/64"		0-20	(fluctuating)		5 100
3:50 pm	8/64"		22			5 100
3:55 pm	16/64"		20			5 125
4:10 pm	16/64"		25			5 100
4:15 pm	12/64"		25			5 125
4:30 pm	12/64"		25			5 125
	Well is weak flow					
	Runs.					