

STATE OF OREGON
 DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES
 1069 State Office Building Portland 1, Oregon

HISTORY OF OIL OR GAS WELL
 (Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator REICHHOLD ENERGY CORPORATION

Field MIST

Well No. C.C. 32-33 RD. #1

, Sec. 33

, T. 6N

R. 5W

W.B. & M.

Signed *Tim Williamson*

Title Drilling Superintendent
 (President, Secretary or Agent)

Date 8-18-82

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date	Description
8- 5-82	Pumped top kick-off plug from 680'-380' WOC
8- 6-82	WOC, pick up Dyna Drill and drilling 6 1/4 hole to 700'
8- 7-82	Drilling 6 1/4 hole @ 1615' <i>KOPN 500'</i>
8- 8-82	Drilling 6 1/4 hole @ 2072'
8- 9-82	Drilling 6 1/4 hole @ 2515'
8-10-82	T.D. 6 1/4 hole @ <u>3030'</u> <i>RD. 1</i>
8-11-82	Logging with Schlumberger, go in hole, set bottom plug from 3030'-2500' and set top plug from 700'-280', WOC
8-12-82	Go in hole and tagged cement @ 389' with Bill King Witnessing
	Released Rig 8-13-82