Headset Model	Picture	Туре	Headset Connection Options	Connection Diagram
Plantronics S12 (CDW Part# 554934)		Wired	Connects directly to headset port on back of phone.	
Plantronics SupraPlus HW261N (CDW Part# 1125601)		Wired		
Plantronics EncorePro 540 (CDW Part#4082549)		Wired	A10-16 cable, which connects to the M12/22 Amplifier (Channel number depends on the headset)	
Plantronics A10-16 Direct Connect Cable ("Quick Release") (CDW Part# 687768)	E.	Wired		
Plantronics M12 / M22 (Amplifier) (CDW Part# 3544818)	1	Wired		
Plantronics CS 530 / 540 (CDW Part# 2701329/2468326)		Wireless		
Plantronics Savi W01	Ĵ	Wireless / PC	Can be used with the headset	

Plantronics Savi W02 (CS730) (replaced the W01) (CDW Part# 2452687)		Wireless / PC / Bluetooth	connector that comes with the headset OR with the Plantronics HL-10 lifter, OR with the Plantronics APS-11 "hook switch".	
Plantronics Savi W740 (CDW Part# 2426801)		Wireless / PC / Bluetooth		<i>See Pictures of the connections of these products to either the Unify 35G or 55G, below this table.</i>
Plantronics Voyager (CDW Part# 2909356)	P	Wireless / Bluetooth		
Phone Interface Cable (included in original package)		N/A	Connects headset base to phone.	
Plantronics HL-10 Lifter (alternative to APS-11 hookswitch, below) (CDW Part# 356186)	200	N/A	Connects to phone base.	
Plantronics APS-11 "Hookswitch" (alternative to HL-10 Lifter) (CDW Part# 2636711)	00	N/A	Connects between phone base and headset base.	USE USE

Incompatible Headsets						
Headset Model	Picture	Туре				
Plantronics C S50 / S55		Wireless				

Plantronics Encore H91	R	Wired	
------------------------	---	-------	--



