

# ZERO BASELINE CALIBRATION

*The Ellipsoidal Distance and the Ellipsoidal Height Difference between two GPS positions = zero*

## Zero Baseline Calibration should be done:

- ✓ annually, according to a schedule set up, administered and maintained by Geometrics Tech Support.
- ✓ If the instrument's integrity is in question (user feels it may have been damaged).





