

Limited Maintenance Specialty Contractor HVAC/R (LHR)

OAR 918-282-0040

The scope of work allowed with a Minor Label is regulated by license type. This does **not** allow any business/person to make an installation or perform any work that is not authorized by the scope of the contractor's and individual's license. Any Minor Label purchased under the Limited Maintenance Specialty Contractor HVAC/R (LHR) license is limited to this scope of work. **Any work done outside of this scope is in violation of the minor label program.** The license number is printed on each label.

Scope of work allowed under a minor label	Individual installer license requirement
Repair or replacement of a furnace, oil or gas , not to exceed 20 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(A)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Repair or replacement of a fan , not to exceed 20 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(B)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Repair or replacement of an electrical furnace, air conditioning unit, or refrigeration unit , where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(E)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>

* Limited maintenance specialty contractor HVAC/R is required to create and maintain an electrical training record within 60 days of hiring for each employee who will do the electrical work.