

ELECTRICAL Minor Label Program

Limited Maintenance Specialty Contractor (LMS)

OAR 918-282-0050

The scope of work allowed with a Minor Label is regulated by license type. This does **not** allow any business/person to make an installation or perform any work that is not authorized by the scope of the contractor's and individual's license. Any Minor Label purchased under the Limited Maintenance Specialty Contractor (LMS) license is limited to this scope of work. **Any work done outside of this scope is in violation of the minor label program.** The license number is printed on each label.

Scope of work allowed under a minor label	Individual installer license requirement
Replacement of a furnace, oil or gas , not to exceed 20 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(A)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Replacement of a fan , not to exceed 20 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(B)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Replacement of a dishwasher or garbage disposal , not to exceed 20 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(C)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Replacement of an electrical furnace, air conditioning unit, or refrigeration unit , where the installation does not exceed 150 volts to ground, single-phase. <i>OAR 918-309-0220(5)(a)(E)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Applications up to 300 volts to ground for the replacement or retrofit of ballasts or other components in up to 10 light fixtures. <i>OAR 918-309-0220(5)(b)</i>	Installer license is not required <i>*Must have list of employees on record with BCD</i>
Replacement of a water heater , which involves an electrical circuit, not to exceed 30 amps, where the installation does not exceed 150 volts to ground, single-phase. <i>Use plumbing minor label.</i> <i>OAR 918-309-0220(5)(a)(D)</i>	One of the following: <ul style="list-style-type: none"> • Water Heater Installer (WHI) (residential) • Journeyman Plumber (JP) (commercial) <i>*Company must also have Plumbing Business (PB) License</i>