


AutoTURN 11

Using the Program in CONNECT

After [AutoTURN 11](#) is installed, you will need to sign out of Windows and log back in, which will configure your computer to run AutoTURN 11. AutoTURN can be launched from the **Tools** tab of the **ODOT** ribbon workflow in MicroStation CONNECT or ORD, if it is installed.

Select the **ODOT** ribbon workflow and then look in the **Add-Ins** group. After you launch the program, you may change back to the Drawing ribbon workflow.



Using the Program in MicroStation V8i SS4

AutoTURN 11 also works within MicroStation V8i SS4 and should be used for current work that was begun using AutoTURN 10. The V8i workspace is frozen, so you have to manually load AutoTURN 11. In MicroStation V8i SS4 use **Utilities > MDL Apps**. Then, **[Browse]** to C:\Program Files\Transoft Solutions\AutoTURN 11 and select at8i.ma.

Or use the key-in: `mdl load "C:\Program Files\Transoft Solutions\AutoTURN 11\at8i.ma"` which can also be assigned to a function key.

Transoft Data

Personal AutoTURN files are stored locally in your profile's AppData folder on the C: drive, rather than in F:\ODOT_DATA\AutoTURN, to make telecommuting and working from home more reliable and faster. A link to your local data is in the **Desktop\Engineering** folder called **My Transoft Content**. The local data that is more than one day old is backed up to F:\ODOT_DATA\Transoft\Backups. You can restore these files yourself, if needed. Because the F: drive is on a server and backed up, even older files can be restored by the Computer Support Desk.

Transoft Documentation

[AutoTURN Pro 11.0 Help - Welcome to AutoTURN Pro Help \(transoftsolutions.com\)](https://www.transoftsolutions.com/help/)

Webinars: <https://www.transoftsolutions.com/webinars/>