AtlanticRichfieldCompany **Daily Well History – Interim**

Instructions: This form is used during drilling or workover operations, testing, coring, or completing, after commencement of operations, and ending with completion or suspension. Number all daily well history forms consecutively as they are prepared for each well. Attach description of all cores. Work performed by Producing Section will be reported on "**Interim**" sheets until final completion. Report official or representative test on "**Final**" form. 1) Submit "**Interim**" sheets when filled out but not less frequently than every 30 days, or 2) on Wednesday of the week in which oil string is set. Submit weekly for workovers and following setting of oil string until completion.

District	County or Parish	State
WESTERN	COLUMBIA COUNTY	OREGON
Field	**Lease or Unit**	**Well no.**
MIST	COLUMBIA COUNTY	32-32

Date and depth as of 8:00 a.m.	Complete record for each day while drilling or workover in progress
6:00 a.m.	1985
11-14	COLUMBIA COUNTY #32-32 - (Mist) - WellTech #451 - AFE # R46079 AET PBD: 1986' - Release rig CASING: 5-1/2" @ 2170' RU N_2 service and lubricator. Test lines, wellhead and choke manifold to 1500 psi. Install perf guns into lubricator. Test lubricator to 1500 psi. RIH with 1-11/16" Enerjet thru tubing gun and perforate 4 HPF from 1972' - 1954' (72 holes). Open well at 1330 hrs, 11-13-85. Flow through blow line to sump until clean. Switch to flare. ISIP = 805 psi. Secure well at 1600 hrs, 11-13-85. Release rig at 1930 hrs, 11-13-85.

The above is correct

Signature	Date	Title
B. E. DAVIS B.E. Davis	2/13/86	DISTRICT DRILLING SUPERVISOR

For form preparation and distribution see Procedures Manual Section 10, Drilling, Pages 86 and 87

AR3B-459-2-A

Number all daily well history forms consecutively as they are prepared for each well. Page no. 3