

# CIVIL PROFILES and ALTERNATING PLANS AND PROFILES

---

CONNECT PLANS PRODUCTION PROCESSES USING MICROSTATION CONNECT


# TOPICS

---

- What's special about Profiles?
- Civil Profile Named Boundaries
- What are Linked Profile Named Boundaries and Do You Have to Use Them?
- Diverting Sheet models to Other DGN Files on the Create Drawing Dialog - DT, PL, PF, PP

# WHAT'S SPECIAL ABOUT PROFILES?

- Alignment profile data is *displayed* by ORD in a dynamic model in the GEOM file
- Dynamic models cannot be attached as references



The screenshot above shows the View Attributes for the Profile – L model in a Geometry file. The Profile model is a dynamic model and not attachable as a reference because it does not appear in the list of permanent models in the Models dialog on the right.

## HOW DO WE DISPLAY PROFILE INFORMATION FOR CONTRACT PLANS?

---

Use OpenRoads Designer to create models that may be attached as references.

**OPNP** and **XSEC\_bas** files are design deliverables.


OpenRoads Designer User Guide:

“Because OpenRoads Designer **does not functionally allow permanent profile graphics to be accessible** to the ODOT plans production process other than in a model created by the OpenRoads Designer, the ORD Standards Committee has agreed that the OpenRoads Designer Plans and Profiles file (**OPNP**) **should be created in all projects** as a container for the project civil design for inclusion on contract plans.”

from Design Deliverables for Plans Production


Designers work with dynamically displayed data and can create the **OPNP** file very early in the design process to display profile information for other disciplines to use in their design, as well as for the plans production process.

# THE OPNP FILE – DRAWING AND SHEET MODELS



Like the GEOM file, the OPNP file will display a dynamic profile model in ORD for placing named boundaries. The dynamic profile model is not available for direct reference attachments but is used to display the profile information for drawing production or other discipline design. The drawing- and sheet-type models outlined in green should be used for plans.

# THE OPNP FILE – CIVIL PLAN AND CIVIL PROFILE NAMED BOUNDARIES



The OPNP file displays a dynamic profile model in ORD for placing named boundaries. The dynamic profile model is not available for direct reference attachments but is used to display the profile information for drawing production or other discipline design. The LongAttachedSection – L model is not found in the Models dialog shown at the right.

# DESIGN DELIVERABLES INFORM PLANS PRODUCTION

---

## The Plans Production Process and Design Deliverables ✕

The CONNECT Processes group along with the ORD and CAD Standards Committees have been working on efficient methods for using both MicroStation CONNECT and OpenRoads Designer to produce contract plans. The following documents explain methods to create the files that display the design using OpenRoads Designer and methods of assembling that data into sheets using MicroStation CONNECT.

- [Design Deliverables for Plans Production](#)
- [Plans Production Process](#)
- [Using OpenRoads Designer and the ODOT Drawing Boundary Seeds](#)
- [Civil Drawing Boundary Sizes](#)
- [ORD and MSCE for Plan and Profile Sheets](#)

The ODOT OpenRoads Designer User Guide and the ODOT MicroStation CONNECT User Guide both contain a section about how ORD is used to create models that can be attached as references for plans production and other discipline design work.

# CIVIL PROFILE NAMED BOUNDARIES

Must have a profile window  
open

Pick a Drawing Seed

Use “Station Limits”

Place Named Boundary Civil Profile

Drawing Seed: Profile Inch 50

Detail Scale: 1"=50'

Name: Profile 1

Description:

Method: Station Limits

Group: (New)

Name: Untitled

Description:

Start Location: 0.000000

Stop Location: 0.000000

Length: 775.000000

Vertical Exaggeration: 10.000000

Available Profile Height: 47.500000

Top Clearance: 0.500000

Bottom Clearance: 0.500000

Elevation Datum Spacing: 5.000000

Station Datum Spacing: 100.000000

Profile Shifts: Datum Stations

Use Terrains

Use Active Vertical

Whole Conduits Only

Create Drawing

Show Dialog


Place Named Boundary Civil Profile > Identify Profile View

Civil Plan boundaries are not required if the method for Civil Profile is set to use Station Limits.



# LINKED PROFILE NAMED BOUNDARIES

- Linked to Plan Stationing for initial placement
- Use Method of “From Plan Group”
- Linked to the Plan Group for Alternating Plan and Profile Drawing Creation




You are not required to create alternating plan and profile drawings. Using the method of “From Plan Group” when placing the civil profile named boundaries gives you the “alternate” option later. You can also create individual drawings of only plan or only profile.

# DIVERTING SHEET MODELS TO OTHER DGN FILES

---

1. Create a DGN in 2\_Plan\_Sheets first
2. Always toggle on the “Show the Create Drawing Dialog” pencil icon.



The “Show the Create Drawing dialog” or Pencil icon provides all options including model name seeds and whether or not to create the models in a different file.

# DIVERTING SHEET MODELS TO OTHER DGN FILES

3. Check the box to use a different file and [Browse] using the folder icon.

The screenshot shows the 'Create Drawing' dialog box with the following settings:

- Mode:** Alternating Plan and Profile
- One Sheet Per Dgn:**
- Plan View (Left Column):**
  - View Name: L - C01
  - Drawing Seed: Plan Inch 50
  - View Type: Civil Plan
  - Discipline: Civil
  - Purpose: Plan View
  - Drawing Model: L - C01
  - Seed Model: ODOT\_All\_Sheets.dgnlib, Plan Inch 50
  - Filename: (Active File) [Browse]
  - Annotation Group: Plan Annotation
  - Sheet Model: L - C01
  - Seed Model: ODOT\_All\_Sheets.dgnlib, Plan Inch 50 [Sh]
  - Filename:  R\_K99999\_pp\_01.dgn [Browse]
  - Sheets: (New)
  - Full Size 1=1
  - Drawing Boundary: Plan Inch 50
  - Detail Scale: 1"=50' (By Named Boundary)
  - Add To Sheet Index
  - Make Sheet Coincident
  - Open Model
- Profile View (Right Column):**
  - View Name: L - Profile1
  - Drawing Seed: Profile Inch 50
  - View Type: Civil Profile
  - Discipline: Civil
  - Purpose: Elevation View
  - Drawing Model: L - Profile1
  - Seed Model: ODOT\_All\_Sheets.dgnlib, Profile Inch 50
  - Filename: (Active File) [Browse]
  - Annotation Group: Profile Grid Large Scale
  - Sheet Model: L - Profile1
  - Seed Model: ODOT\_All\_Sheets.dgnlib, Profile Inch 50 [
  - Filename:  R\_K99999\_pp\_01.dgn [Browse]
  - Sheets: (New)
  - Full Size 1=1
  - Drawing Boundary: Profile Inch 50
  - Detail Scale: 1"=50' (By Named Boundary)


You are not required to create alternating plan and profile drawings. Using the method of “From Plan Group” when placing the civil profile named boundaries gives you the “alternate” option later. You can also create individual drawings of only plan or only profile.

# DEMO

Use ProjectWise to create a PP file.

Use ORD in OPNP file; verify the Civil Plan named boundaries created earlier; place Civil Profile boundaries; divert drawings to PP file.

Use MSCE in PP file to create PDF.



# QUESTIONS? A LOOK AHEAD

---

## **November 16 - CONNECT Plans Production Processes using MicroStation CONNECT**

- Design Deliverables - OPNP/XEC\_bas, TERR\_CF, CORR\_CF, GEOM\_CF
- Plan Sheet Creation with Source Data from OPNP File or XSEC\_bas File
- How to create a named boundary model containing a sheet layout of clip shapes