

STATE OF OREGON
DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES
1069 State Office Building Portland 1, Oregon

HISTORY OF OIL OR GAS WELL

(Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator John T. Miller


Field Polk County wildcat

Well No. Berk # 1

, Sec. 26 , T. 8South R. 5West

W.B. & M.

Signed



Title

(President, Secretary or Agent)

Date May 21, 1981

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date

Spudded 11-12-80

Drilled 13" hole to 100 ft., set 100 ft. of 10" OD cemented with 30 sacks

Drilled 2 ft. cement out of bottom of 10" surface pipe with 8" bit.

Drilled 8" hole to 460 ft., run 460 ft. 6 5/8 OD. Made formation seat.

Drilled 6" hole to 780 ft. Run 4 1/2" OD and made formation seat.

Drilled 4" hole to 1030 ft., pulled 4 1/2" pipe and set 25 ft. cement plug

at 700 to 725 ft. Run 4 1/2" with packer and tested sands 580 to 700 ft.

Small gas flow and 15 bbl salt water per day. Pulled 4 1/2" pipe and 6 5/8"

pipe. Set 115 ft. cement plug from 550 to 665 ft. (43 sacks) Set

110 ft. cement plug from 40 to 150 ft. (47 sacks)

Cut 10" off 2 ft. below ground, welded plate with 1" collar and 1" plug

on pipe. Covered well with dirt and filled in pit 5-21-81