Operator

Well No.

## STATE OF OREGON DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES Portland 1, Oregon 1069 State Office Building

## HISTORY OF OIL OR GAS WELL (Submit in duplicate)

Field

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

, Sec. 32

Reichhold Energy Corporation

RECEIVED-PILD

W.B. & M.

DEPT OF GEOLOGY

Mist

October 3, 1984 Date

Paul 34-32 RD#2.

Title Field Operations Supervisor

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date

- 9/19/84 WOC. Drilling cement. Trip in with navidrill. Kick off at 710'. Drilling 7 7/8" hole & surveying to 770'
- 9/20/84 Drlg. & surveying to 1238'. Build and hold angle to 5° N 10 E. 1205' TVD = 1203.54 & total course coordinates = 35.84' N and 10.12' E.
- 9/21/84 Drlg. & Surveying to 1590'. Drop angle to 1°15' N 20 W. 1425', TVD = 1423.82 & total course coordinates = 44.16' N & 9.41' E
- 9/22/84 Drlg & surveying to 2203'. Maintain angle at 1°
- 9/23/84 Drlg & surveying to 2553'. Hold angle to 0°45' N 27 W. At 2526 TVD = 2524.67 & total course coordinates = 57.53' N & .99' W
- 9/24/84 Drlg & surveying to 2719 or TD. AT TD TVD = 2717.66 and total course coordinates = 58.52' N & 2.35' W. Wiper trip to shoe. Rig up loggers and run wireline logs. RIH, circ. & wait on orders
- 9/25/84 Wait on orders. Run in hole open ended to 2582 and set cement plug to 2482 with 30 sx class "G" cement. Pull up to 710 and set plug to 447 with 110 sx class "G" cement
- 9/26/84 RIH & tag plug @ 497. Set plug @ 497 447 with 20 sx class "G" cement. WOC RIH & tag plug @ 447 with Dennis Olmstead witnessing.
- 9/27/84 Load out tools, clean mud pits.

Release rig @ 4:00 p.m. 9/27/84