

Randall Ranch

Feedlot

RECEIVED

JUL 21 2008

NATURAL RESOURCES  
DIVISION


181161

Ampt


08 060

**Animal Waste Management Plan**


**Summary of CAFO Operation**




**Specific Descriptions &  
Calculations**



**Record Keeping & Reporting  
Requirements**



**Large CAFO Additional  
Requirements**



**Miscellaneous**



**Contact Name, Address, Phone Number**

**Facility Address**

**Type of Operation**

**Number and size of animals by species**

**Manure, litter and process waste system- provide a general narrative description of each**

**Collection-** How is manure, litter and process waste removed from housing, confinement lot? How is clean water diverted from storage?

**Storage-** Types and size of manure, litter and process waste storage tanks, ponds

**Transfer-** How is manure, litter and process waste moved to storage, application areas?

**Use-** How is manure, litter and process waste treated (composted, separated, anaerobic digestion or storage, aeration)? How is manure, litter and process waste water used on crops? If export is utilized, describe that process

# Animal Waste Management Plan

July 10, 2008

## Randall Ranch Feedlot

### Operated by:

Rocky Randall  
42742 New Bridge Road  
Richland, Oregon 97870  
(541) 893-6232

### Facility Address:

42866 New Bridge Road  
Richland, Oregon 97870

### Operation:

Beef Feedlot  
Medium Federal CAFO

As owner and operator of Randall Ranch Feedlot. I intend to manage in accordance with the practices and operation and maintenance described in this Animal Waste Management Plan.

Signature Rocky Randall

Date 7-10-08

## GENERAL NARRATIVE DESCRIPTION

Randall Ranch Feedlot is located at 42866 New Bridge Road in Richland, Oregon and is owned by John Randall and operated by Rocky Randall. The operation is a beef back grounding feedlot and is set on 400 acres available for manure application in Baker County. The beef feedlot is in full operation from September through May at which time, animal numbers may reach 600 head. The cattle are of mixed breeds. A majority of young animals are brought on to the feedlot each fall at a weight of approximately 500 pounds. Most animals are shipped off the operation in the spring at approximately 750 pounds. The average weight of the animals during the confinement period is 625 pounds.

### Manure Collection Methods

All cattle are confined in earthen pens. The manure is collected in the pens where it dehydrated and used as bedding for the cattle. When the cattle are removed from the facility, the pens are cleaned and the dry manure is used as a soil amendment when any excess accumulates. At this time the manure is left in the pens, mounded and packed for bedding in the fall.

No ponds are necessary to catch contaminated runoff that may occur during a large winter storm event because the pens are flat. Earthen berms and grass filter strips are maintained around the pens to reduce potential for runoff during a storm.

### Manure Storage Facilities and Transfer

The manure generated at the facility is handled in a dry solid form. Dry manure is scraped and stacked within feedlots during the confinement period, and then land applied during the growing season if excess accumulates. All manure will be contained within the facilities. Clean water is diverted around

the system, except in extreme conditions, when some rainfall enters the feedlots.

All liquid that is collected in the pens evaporates due to the dry climate (9.97" average annual rainfall, 40.23" average annual evaporation). Solids that are collected in the pens are cleaned out every five years, or as needed. The solids are applied to crop ground.

The solid manure is stored within the dry lots. Solid manure is transported to fields using a dump truck if necessary.

Corn silage is stored in a 60' x 110' earthen bunker. All leachate and contaminated runoff is contained and evaporated.

#### Manure Utilization

The land available for manure application is owned and/or leased by Rocky Randall. There are 400 acres adjacent to the operation that available. Currently, 100 acres of alfalfa which yields 6.5 tons per acre, 60 acres of corn silage which yields 30 tons (as-fed) per acre, 240 of irrigated grass for hay and grazing. The crops are used as feed in a high roughage ration for the cattle. Additional feedstuffs are imported to the feedlot.

Manure is applied via a dump truck and landplane if necessary. Dry manure will be spread in a grass-corn rotation if necessary. No manure is applied to the alfalfa at this time. Approximately 100% of the dry manure is used for winter bedding at this time.

Manure is not only used for nutrient benefits, but also to improve soil tilth via the inputs of organic material. This plan is balanced for nitrogen production and use.

**ANIMAL WASTE MANAGEMENT PLAN  
MINIMUM REQUIRED ELEMENT**

OPERATION AND MAINTANENCE

**Randall Ranch Feedlot**

Name of Operation

Mark all that apply to your operation.



Animal Access Lanes or Walkways

Damaged components will be repaired or replaced as needed. Debris and excess manure will be removed from roadway surfaces, road ditch and drainage areas. Maintain drainage area capacities. Maintain good vegetative cover on all slopes and watercourses.



Culverts

Inspect annually or after large rainfall event. All foreign objects restricting water flow will be removed. Damaged sections will be repaired or replaced. Erosion around inlet or outlet will be corrected.



Dry Stack Storage Facility

Solid manure storage facility will be inspected annually. Broken slabs and curbs will be repaired. Repair or replace rusted or damaged areas on roof structure. Broken gutters and/or downspouts will be repaired or replaced. Check for adequacy and function of drain away from downspouts. Check floor, side and back walls for soundness. Manure solids and leachate will not escape through cracks in the facility.



Feedlot Pens

*(ODA does not advise long-term manure storage in open feedlot pens, even in low rainfall areas. Research is currently underway to determine environmental impacts of such practices.)*

Maintaining a firm, dry feedlot surface is an important factor in good animal health and the environment. Diversion ditches or berms should direct clean water flow away from feedlot pens and holding areas. Storm water runoff from pens will be collected and stored appropriately. Dry manure will be contained within the pen until removed for storage or field application. Manure accumulations created by manure packs or mounding will be managed such that a pollution hazard is not created. Short-term mounding may be used in conjunction with quick clean-ups used to reduce manure pack from around aprons and under fences. Manure will be removed annually from pens. When removing manure from pens, care is taken to maintain the integrity of the compacted protective seal or "hard pan".



Fencing

Fences will be inspected periodically. Broken or decayed posts will be replaced. Sagging wire will be tightened. Broken wire will be spliced or replaced. Broken or missing insulators for electric fencing will be replaced. Vegetation will be controlled under the fences. Electric fencing will be sufficiently charged to detour animals.

☒ Irrigation Water Management

Irrigation water application will be at rates that minimize transport of sediment, nutrients, and chemicals to surface water and ground water. Equipment modifications and/or soil amendments such as polyacrylamides and mulches should be considered to reduce erosion if needed.

☒ Filter Strips

Maintain vigorous growth of vegetative covering. This includes reseeding, fertilization and application of herbicides when necessary. Periodic mowing, harvesting or grazing may also be needed to control height. Remove all foreign debris that hinders system operation. Limit the traffic from filter strip area. Limit livestock usage to vegetative growth periods when the animals will not damage vegetative root system or compact the soil. Eradicate or otherwise remove all rodents or burrowing animals. Immediately repair any damage.

☐ Manure Application Equipment

All manure application equipment (including but not limited to sprinklers, big gun irrigators, spreaders and/or tank wagons) will be operated and maintained according to the manufacturer's manual. Equipment found to be broken or worn will be replaced. Equipment will be calibrated to ensure recommended rates are applied. Liquids will be drained from sprinklers or big guns prior to freezing weather. When system is flushed, rinse water is used following waste, and liquid and sediment is applied agronomically. Nozzles will be checked periodically and if worn, nozzles will be replaced. Minimize exposure to animal and organic wastes and manure gasses. Wear protective clothing when appropriate. When cleaning equipment after nutrient application, remove and save wastes in an appropriate manner. Avoid applying manure near surface water by establishing buffer strips and set backs, and use extreme care to avoid contaminating ground water.

☐ Manure Effluent and Irrigation Transfer Lines.

Manure, effluent and irrigation lines shall be flushed with clean water periodically to prevent particle buildup and plugging. Manure flushed from the lines will be applied agronomically so that surface and groundwater will be protected. Manure, effluent and irrigation lines shall be inspected periodically for leaks or worn out nozzles, and repairs or replacements made as needed. Special inspection shall be done to pressure relief valves, risers and control valves. Shut off valves will be inspected annually. Avoid unnecessary travel over pipelines that will damage their integrity. Equipment found to be broken or worn will be replaced. Water will be drained during cold weather to prevent frozen or broken lines. These lines can explode if not properly maintained and may cause human injury.

☐ Pumps

Pumps will be maintained in accordance with manufacturer's operation and maintenance manual. Effluent will be drained from pumps prior to freezing weather. Pumps will be inspected periodically to identify and remove debris wrapped around impeller or worn parts. Appropriate action will be taken to repair any worn parts. Liquids will be drained from pump prior to freezing weather to prevent breakage. It is recommended to have a spare pump or back up system in case a pump must be removed for an extended time for repair.

☒ Trough or Tank

Watering facility will be inspected periodically. Damaged tank/trough will be repaired or replaced. Float valves will be maintained in good working order. Area immediately surrounding the

trough/tank will be maintained in a stable condition. Watering facilities will not be allowed to overflow if additional liquid will affect waste storage capacities.



Evaporation Waste Storage Pond

Prior to the storage season, empty the pond to provide storage capacity for the accumulation of wastewater and precipitation during the winter storage period. Sludge and accumulated solids will be removed from the pond periodically when buildup limits storage capacity in the pond. Depth markers are installed to assure maximum volume will be maintained and checked weekly. A 2-foot free board will be maintained to prevent spillage.

Maintain all pumps, pipeline, valves, and electrical and mechanical equipment in good operating condition following the manufacturer's recommendations. Immediately repair any vandalism, vehicular, or livestock damage to any earth fill. Immediately remove any obstructions or blockage of spillways, trash racks or pipe inlets. Settlement or cracks in earthen sections should be investigated to determine cause and immediately repaired. Maintain vigorous growth of vegetative coverings on the dikes to eliminate soil erosion. Eradicate or otherwise remove all rodents or burrowing animals and repair any damage caused by their activity. Fences and/or warning signs should be maintained as necessary to unauthorized human or livestock entry. Operate systems in a manner that minimizes odor and drift.



---

---

---



---

---

---

---

Signature of Legally Authorized Representative:

*Rocky Randall*

Print Name:

*Rocky Randall*

Date:

*7-10-08*

## **Narrative of production area & land application locations**

**Aerial photo/topographical map showing numbered fields, production area, clean water diversions, surface water features  
Soil maps of all application fields & map unit descriptions**

## **Manure, Litter and Process Waste Volumes**

**Manure, litter and process waste output collected & stored in this system. Bedding added & collected. Processed & wash water collected. Silage & feed processing leachate**

## **Contaminated Storm Water**

**Direct rainfall into storage, slab or lot runoff collected, overflow from gutters or diversions**

## **Nutrient Content of Manure, Litter & Processed Waste**

**Content & volume of nutrients in manure, litter & process waste generated. Actual test values are required of large CAFOs**

## **Farm Nutrient Balance**

**Show amount of nutrients (N,P,K) generated, lost in storage, lost in application, or exported off farm annually. Nutrient applications must balance to most limiting nutrients as determined by NRCS Agronomy Tech Note 26 & NRCS Phosphorus Index. Include all acres required to balance nutrients owned or leased by the operator**

## **Application Schedule & Limitations**

**Show scheduled applications of solids & liquids. Include date, amount & method of application to identified fields, describe calibration of equipment used to apply manure, litter & processed waste. Describe limitations to applications, indicate buffer areas & management to avoid frozen or saturated soils. Justify buffer width & management. Calculate the minimum storage required for liquids & solids. Indicate timing & application rates of irrigation water, irrigation must not allow leaching of soluble nutrients or runoff**

## **Animal Mortality Management**

**Describe how the farm handles mortalities**

## **SPECIFIC DESCRIPTIONS AND CALCULATIONS**

### Land Application Areas

Aerial photos showing numbered field locations for all manure application acreage and surface water features, a topography map and a schematic of the feedlot headquarters are included in this Animal Waste Management Plan.

There are 7 soil types found on the property including, 12A, 12B Baker Silt Loam, 15A Balm Loam, 16B Barnard Silt Loam, 23A Boyce Silt Loam, 40A Cumulic Haploxerolls and 127A Powval Silt Loam. A soils map and soil map unit descriptions for all manure application areas are included in this Animal Waste Management Plan.

### Manure and Waste Volumes

Calculated volumes of all manure, bedding, silage leachate, and contaminated storm water have been completed using an excel worksheet based from the NRCS Agricultural Waste Field Handbook. The worksheet is included in this Animal Waste Management Plan.

### Nutrient Content of Manure, Little and Process Waste Water

The same excel worksheet was used to estimate volume of manure. OSU book values are used in the worksheet to estimate manure nutrient content.

### Farm Nutrient Balance

The excel worksheet also includes calculated data for nutrient balance for the operation. Randall Ranch Feedlot is balancing for nitrogen which is the most limiting nutrient as determined by the NRCS Phosphorus Index, which indicated a Site Vulnerability Class of MEDIUM.

### Application Schedule and Limitations

Solid manure is applied and incorporated into the soil primarily in the spring and late summer of each year if necessary. Manure applied to the corn ground is incorporated and planted, if applied in the spring. Manure applied to corn ground in the fall is incorporated then the soil is bedded for the corn and planted in the spring.

Irrigation water from Eagle Creek is used on all of the manure application acreage. Flood irrigation is used from April through September. To decrease non-point source pollution of surface and groundwater resources, irrigation water is applied at the volume, frequency and application rate in a planned conservation management system. An irrigation system adapted for the site conditions (soil, slope, crop grown, climate, and water quantity) will be available and capable of applying water to meet the intended purpose. Water will not be applied at rates of more than 2 inches per application or at rates that exceed soil infiltration or crop ET. No tile lines or other form of artificial drainage are used on the property.

A 30 foot vegetated buffer along the Creek and irrigation ditches is in place that does not receive manure applications if manure needed to be applied. This area is naturally vegetated with grasses.

### Animal Mortality Management

Deceased animals are removed from the facilities and buried following State guidelines.

## WATER, WASTE, AND NUTRIENT COMPUTATIONS

### Number of Animals

|              | Animals    | Avg. Weight<br>lb | Total 1000#<br>Animal Units | Confinement<br>Period (Days) |
|--------------|------------|-------------------|-----------------------------|------------------------------|
| 1            | 600        | 625               | 375                         | 210                          |
| 2            |            |                   | 0                           |                              |
| <b>Total</b> | <b>600</b> | <b>625</b>        | <b>375</b>                  |                              |

Solid Storage (Feedlot pen size)

Pens 1-5      5 acres

Evaporation Ponds for storm runoff

### Total weight and volume of manure produced during confinement

\*Estimated values from NRCS Agricultural Waste Management Handbook)

#### Manure Produced

|              | lb/day/Animal Unit | Total Weight<br>ton (as excreted) | Total Weight<br>ton (at application) |
|--------------|--------------------|-----------------------------------|--------------------------------------|
| 1            | 58.2               | 2292                              | 687                                  |
| 2            |                    | 0                                 | 0                                    |
| <b>Total</b> |                    | <b>2292</b>                       | <b>687</b>                           |

|              | Cu ft/day/Animal Unit | Total Volume<br>Cu ft |
|--------------|-----------------------|-----------------------|
| 1            | 0.93                  | 73238                 |
| 2            |                       | 0                     |
| <b>Total</b> |                       | <b>73238</b>          |

### Total Nutrient Production

\*Estimated values from NRCS Agricultural Waste Management Handbook

|            | Nutrients Produced<br>lb/day | Total Nutrients Produced<br>lb |
|------------|------------------------------|--------------------------------|
| Nitrogen   | 0.30                         | 23625                          |
| Phosphorus | 0.10                         | 7875                           |
| Potassium  | 0.20                         | 15750                          |

### Nutrient Losses

\*Estimate from NRCS ORAWM Program and OSU Extension Publication EC 1094

| Loss            | Remaining N | Remaining P | Remaining K |
|-----------------|-------------|-------------|-------------|
| Storage         | 50%         | 70%         | 60%         |
| Application     | 70%         | 100%        | 100%        |
| Denitrification | 95%         | 100%        | 100%        |

| Loss            | Remaining N<br>lbs | Remaining P<br>lbs | Remaining K<br>lbs |                               |
|-----------------|--------------------|--------------------|--------------------|-------------------------------|
| Storage         | 11813              | 5513               | 9450               |                               |
| Application     | 8269               | 5513               | 9450               |                               |
| Denitrification | <b>7855</b>        | <b>5513</b>        | <b>9450</b>        | Available for crop production |

### Nutrients Utilized

\*Estimate from NRCS ORAWM Program

| Crop         | Acres    | Yield Units<br>per acre | Yield | N Utilized<br>(lbs/acre) | P Utilized<br>(lbs/acre) | K Utilized<br>(lbs/acre) |
|--------------|----------|-------------------------|-------|--------------------------|--------------------------|--------------------------|
| Alfalfa      |          | ton                     |       |                          |                          |                          |
| Corn, silage |          | ton                     |       |                          |                          |                          |
| Corn, grain  |          | ton                     |       |                          |                          |                          |
| Wheat, grain |          | bushel                  |       |                          |                          |                          |
| <b>Total</b> | <b>0</b> |                         |       |                          |                          |                          |

### Volume and Nutrients Exported

100% of the manure is used for winter bedding

| Exported<br>tons | N exported<br>lbs | P exported<br>lbs | K exported<br>lbs |
|------------------|-------------------|-------------------|-------------------|
| <b>687</b>       | <b>7855</b>       | <b>5513</b>       | <b>9450</b>       |

Nutrients remaining for crop production on farm **after** export

| Remaining N<br>lbs | Remaining P<br>lbs | Remaining K<br>lbs |
|--------------------|--------------------|--------------------|
| <b>0</b>           | <b>0</b>           | <b>0</b>           |

### Crop Utilization

| Crop         | Acres<br>needed | lbs of N<br>applied | lbs of P<br>applied | lbs of K<br>applied |
|--------------|-----------------|---------------------|---------------------|---------------------|
| Alfalfa      |                 | 0                   | 0                   | 0                   |
| Corn, silage |                 | 0                   | 0                   | 0                   |
| Corn, grain  |                 | 0                   | 0                   | 0                   |
| Wheat, grain |                 | 0                   | 0                   | 0                   |
| <b>Total</b> | <b>0</b>        | <b>0</b>            | <b>0</b>            | <b>0</b>            |

| Gross Nutrient<br>Balance | Acres    | lbs of N | lbs of P | lbs of K |
|---------------------------|----------|----------|----------|----------|
|                           | <b>0</b> | <b>0</b> | <b>0</b> | <b>0</b> |

### Climatic and Hydrologic Data

Climatic Station- Malheur Branch Experiment Station

25 year- 24 hour storm rainfall = 1.8 inches

| Month         | Average Monthly in Inches |              | % Lot Runoff Factors |         |
|---------------|---------------------------|--------------|----------------------|---------|
|               | Precipitation             | Evaporation  | Concrete*            | Unpaved |
| January       | 1.26                      | 0.74         | 100                  | 0       |
| February      | 0.98                      | 1.09         | 100                  | 0       |
| March         | 0.92                      | 2.06         | 100                  | 0       |
| April         | 0.70                      | 3.79         | 100                  | 0       |
| May           | 0.98                      | 5.12         | 100                  | 0       |
| June          | 0.83                      | 6.08         | 100                  | 0       |
| July          | 0.19                      | 7.62         | 100                  | 0       |
| August        | 0.38                      | 6.51         | 100                  | 0       |
| September     | 0.49                      | 4.03         | 100                  | 0       |
| October       | 0.71                      | 1.98         | 100                  | 0       |
| November      | 1.21                      | 0.50         | 100                  | 0       |
| December      | 1.32                      | 0.71         | 100                  | 0       |
| <b>Annual</b> | <b>9.97</b>               | <b>40.23</b> |                      |         |

\*No concrete lot runoff contributing to the manure system.

Soil Map—Baker County Area, Oregon  
(Randall Ranch Feedlot)



Natural Resources  
Conservation Service

Web Soil Survey 2.0  
National Cooperative Soil Survey

# Soil Map—Baker County Area, Oregon (Randall Ranch Feedlot)

## MAP LEGEND

|  |                        |  |                       |
|--|------------------------|--|-----------------------|
|  | Area of Interest (AOI) |  | Very Stony Spot       |
|  | Area of Interest (AOI) |  | Wet Spot              |
|  | Soils                  |  | Other                 |
|  | Soil Map Units         |  |                       |
|  | Special Point Features |  | Special Line Features |
|  | Blowout                |  | Gully                 |
|  | Borrow Pit             |  | Short Steep Slope     |
|  | Clay Spot              |  | Other                 |
|  | Closed Depression      |  |                       |
|  | Gravel Pit             |  | Political Features    |
|  | Gravelly Spot          |  | Public Land Survey    |
|  | Landfill               |  | Township and Range    |
|  | Lava Flow              |  | Section               |
|  | Marsh                  |  | Municipalities        |
|  | Mine or Quarry         |  | Cities                |
|  | Miscellaneous Water    |  | Urban Areas           |
|  | Perennial Water        |  |                       |
|  | Rock Outcrop           |  | Water Features        |
|  | Saline Spot            |  | Oceans                |
|  | Sandy Spot             |  | Streams and Canals    |
|  | Severely Eroded Spot   |  |                       |
|  | Sinkhole               |  | Transportation        |
|  | Slide or Slip          |  | Rails                 |
|  | Sodic Spot             |  | Roads                 |
|  | Spoil Area             |  | Interstate Highways   |
|  | Stony Spot             |  | US Routes             |
|  |                        |  | State Highways        |
|  |                        |  | Local Roads           |
|  |                        |  | Other Roads           |

## MAP INFORMATION

Original soil survey map sheets were prepared at publication scale. Viewing scale and printing scale, however, may vary from the original. Please rely on the bar scale on each map sheet for proper map measurements.

Source of Map: Natural Resources Conservation Service  
Web Soil Survey URL: <http://websoilsurvey.nrcs.usda.gov>  
Coordinate System: UTM Zone 11N

This product is generated from the USDA-NRCS certified data as of the version date(s) listed below.

Soil Survey Area: Baker County Area, Oregon  
Survey Area Data: Version 4, Dec 21, 2006

Date(s) aerial images were photographed: 6/23/1994

The orthophoto or other base map on which the soil lines were compiled and digitized probably differs from the background imagery displayed on these maps. As a result, some minor shifting of map unit boundaries may be evident.

## Map Unit Legend

| Baker County Area, Oregon (OR604) |                                               |              |                |
|-----------------------------------|-----------------------------------------------|--------------|----------------|
| Map Unit Symbol                   | Map Unit Name                                 | Acres in AOI | Percent of AOI |
| 12A                               | Baker silt loam, 0 to 2 percent slopes, warm  | 13.6         | 12.5%          |
| 12B                               | Baker silt loam, 2 to 7 percent slopes, warm  | 0.3          | 0.3%           |
| 15A                               | Balm loam, 0 to 3 percent slopes              | 12.9         | 11.9%          |
| 16B                               | Barnard silt loam, 2 to 7 percent slopes      | 7.9          | 7.3%           |
| 23A                               | Boyce silt loam, 0 to 2 percent slopes        | 31.5         | 28.9%          |
| 40A                               | Cumelic Haploxerolls, 0 to 2 percent slopes   | 13.8         | 12.6%          |
| 127A                              | Powval silt loam, 0 to 3 percent slopes, warm | 23.9         | 21.9%          |
| W                                 | Water                                         | 5.0          | 4.6%           |
| Totals for Area of Interest (AOI) |                                               | 109.0        | 100.0%         |

grayish brown extremely cobbly loam about 17 inches thick. The substratum to a depth of 60 inches or more is light brownish gray extremely cobbly sandy loam.

Included in this unit are small areas of Segundo soils. Also included are small areas of Anatone and Stavely soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate in the Baldridge soil. Available water capacity is 3 to 8 inches. The effective rooting depth is 60 inches or more. Runoff is rapid, and the hazard of water erosion is high.

This unit is used mainly for livestock grazing. It also provides habitat for many kinds of wildlife.

*Livestock grazing.*-The potential plant community on this unit is dominated by mountain big sagebrush, buckwheat, bluebunch wheatgrass, and needlegrass.

Bluebunch wheatgrass is the major forage-producing plant. If the site is in excellent condition, the total annual production is estimated at 1,600 pounds per acre in favorable years and 900 pounds per acre in unfavorable years. Livestock access is limited by the slope.

If the condition of the site deteriorates through overgrazing, bluebunch wheatgrass loses vigor and decreases in extent. Blue wildrye, buckwheat, and mountain big sagebrush increase in extent. If deterioration continues, the extent of needlegrass and blue wildrye decreases and annual grasses and forbs invade the site.

Mechanical treatment for brush control or range seeding is not practical because of the slope.

The Baldridge soil is in the High Mountain South 16-20pz range site.

**14F-Baldridge very gravelly loam, 50 to 70 percent south slopes.** This deep, well drained soil is on mountains. It formed in colluvium derived from rhyolite and andesite. Areas are irregular in shape and are 80 to 200 acres in size. The native vegetation is mainly bunchgrasses, shrubs, and forbs. Elevation is 4,000 to 6,000 feet. The average annual precipitation is 16 to 20 inches, the average annual air temperature is 40 to 45 degrees F, and the average frost-free period is 60 to 90 days.

Typically, the surface layer is very dark brown very gravelly loam about 14 inches thick. The upper part of the subsoil is very dark grayish brown very gravelly loam about 16 inches thick. The lower part is dark grayish brown extremely cobbly loam about 17 inches thick. The substratum to a depth of 60 inches or more is light brownish gray extremely cobbly sandy loam.

Included in this unit are small areas of Segundo soils. Also included are small areas of Anatone and

Stavely soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate in the Baldridge soil. Available water capacity is 3 to 8 inches. The effective rooting depth is 60 inches or more. Runoff is rapid, and the hazard of water erosion is very high.

This unit is used mainly for livestock grazing. It also provides habitat for many kinds of wildlife.

*Livestock grazing.*-The potential plant community on this unit is dominated by mountain big sagebrush, buckwheat, bluebunch wheatgrass, and needlegrass.

Bluebunch wheatgrass is the major forage-producing plant. If the site is in excellent condition, the total annual production is estimated at 1,600 pounds per acre in favorable years and 900 pounds per acre in unfavorable years. Livestock access is limited by the slope.

If the condition of the site deteriorates through overgrazing, bluebunch wheatgrass loses vigor and decreases in extent. Blue wildrye, buckwheat, and mountain big sagebrush increase in extent. If deterioration continues, the extent of needlegrass and blue wildrye decreases and annual forbs and grasses invade the site.

Mechanical treatment for brush control and range seeding is not practical because of the slope.

The Baldridge soil is in the High Mountain South 16-20pz range site.

**15A-Balm loam, 0 to 3 percent slopes.** This deep, somewhat poorly drained soil is on flood plains. It formed in stratified, mixed alluvium. Areas are elongated and are 20 to 150 acres in size. The native vegetation is mainly water-tolerant grasses and sedges. Elevation is 2,000 to 3,400 feet. The average annual precipitation is 9 to 12 inches, the average annual air temperature is 47 to 51 degrees F, and the average frost-free period is 120 to 140 days.

Typically, the surface layer is about 2 inches of very dark brown loam and 10 inches of very dark brown silt loam. The next layer is dark brown, mottled silt loam about 5 inches thick. The upper 13 inches of the substratum is dark olive gray, mottled silt loam and very dark gray fine sandy loam. The lower 30 inches is multicolored very gravelly sand. Depth to the contrasting substratum is 20 to 40 inches.

Included in this unit are small areas of Baldock, Boyce, Wingville, and Wingdale soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate to a depth of about 30 inches in the Balm soil and very rapid below that depth. Available water capacity is 4 to 7 inches. The effective

rooting depth is limited by a seasonal high water table at a depth of 1 to 2 feet in winter and early summer. This soil is subject to rare flooding. Runoff is slow, and the hazard of water erosion is slight.

This unit is used mainly for hay and pasture. It also provides habitat for many kinds of wildlife.

*Hay and pasture.*-If this unit is used for hay and pasture, the main limitation is the seasonal high water table. Wetness limits the choice of plants and the period of cutting or grazing and increases the risk of winterkill.

Grazing during wet periods results in compaction of the surface layer, poor tilth, and excessive runoff. Conducting fieldwork during wet periods results in deterioration of tilth and destroys soil structure. As a result, it increases the runoff rate and the hazard of erosion. Compaction limits the movement of air and water in the soil and restricts the growth of roots.

Fertilizer is needed to ensure the optimum growth of grasses and legumes.

In summer irrigation is needed for the maximum production of hay. Controlled surface irrigation is a suitable method of applying water. Leveling helps to ensure the uniform application of water. To avoid overirrigation and the leaching of plant nutrients, applications of irrigation water should be adjusted to the available water capacity, the rate of water intake, and the needs of the crop.

Proper stocking rates, pasture rotation, and restricted grazing during wet periods help to keep the pasture in good condition and control erosion. Periodic mowing and clipping help to maintain uniform growth and prevent selective grazing.

This soil is generally unsuited to the trees and shrubs grown as windbreaks and environmental plantings. Onsite investigation is needed to identify areas where trees and shrubs can be planted if special management is applied.

The Balm soil is in the Meadow range site.

**16B-Barnard silt loam, 2 to 7 percent slopes.** This well drained soil is on terraces. It is moderately deep to a duripan. It formed in alluvial sediments influenced by volcanic ash in the surface layer. Areas are irregular in shape and are 100 to 400 acres in size. The native vegetation is mainly bunchgrasses, forbs, and shrubs. Elevation is 2,300 to 3,500 feet. The average annual precipitation is 9 to 12 inches, the average annual air temperature is 47 to 51 degrees F, and the average frost-free period is 100 to 140 days.

Typically, the surface layer is very dark grayish brown silt loam about 7 inches thick. The next layer is dark brown silty clay loam about 7 inches thick. The upper part of the subsoil is dark brown silty clay about 8 inches thick. The lower part is a silica-cemented

duripan about 8 inches thick. The substratum to a depth of 60 inches or more is pale brown very gravelly loam. The depth to a duripan is 20 to 40 inches.

Included in this unit are small areas of Barnard cobbly silt loam. Also included are small areas of Baker and Ruckles soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate to a depth of about 14 inches in the Barnard soil and slow between that depth and the impermeable duripan. It is rapid in the substratum. Available water capacity is 3 to 6 inches. The effective rooting depth is 20 to 40 inches. Runoff is slow, and the hazard of water erosion is slight or moderate.

This unit is used mainly for irrigated hay and pasture or small grain. It also is used for homesite development, and it provides habitat for many kinds of wildlife.

*Hay and pasture or cropland.*-If this unit is used as hayland, pasture, or cropland, the main limitation is the rooting depth. Ripping and shattering the duripan increase the effective rooting depth and improve internal drainage.

Management that maintains the optimum vigor and quality of forage plants is needed. Proper stocking rates, pasture rotation, and restricted grazing during wet periods help to keep the pasture in good condition and control erosion. Periodic mowing and clipping help to maintain uniform growth and prevent selective grazing.

In summer irrigation is needed for maximum crop production. Sprinkler irrigation is a suitable method of applying water. It permits the even, controlled application of water, helps to control runoff, and minimizes the risk of erosion. To avoid overirrigation and the leaching of plant nutrients, applications of irrigation water should be adjusted to the available water capacity, the rate of water intake, and the needs of the crop.

Fertilizer is needed to ensure the optimum growth of grasses, legumes, and other crops. Returning all crop residue to the soil and using a cropping system that includes grasses, legumes, or grass-legume mixtures help to maintain fertility and tilth.

Conducting fieldwork during wet periods results in deterioration of tilth and destroys soil structure. As a result, it increases the runoff rate and the hazard of erosion. Runoff and erosion can be controlled by crop residue management and by rough or minimum tillage. All tillage should be on the contour or across the slope.

Grazing during wet periods results in compaction of the surface layer, poor tilth, and excessive runoff. Compaction limits the movement of air and water in the soil and restricts the growth of roots.

A wide variety of trees and shrubs can be grown as

annual increment for ponderosa pine is 72 cubic feet per acre per year (5.0 cubic meters per hectare per year) in a 40-year-old, even-aged, fully stocked stand and for Douglas-fir is 54 cubic feet per acre per year (3.8 cubic meters per hectare per year) in a 106-year-old, even-aged, fully stocked stand.

The main concerns in producing and harvesting timber on this unit are the hazard of erosion, the equipment limitation, seedling mortality, the hazard of windthrow, plant competition, and fire damage to the soil.

Minimizing the risk of erosion is essential in areas where timber is harvested. Properly designed road drainage systems that include carefully located culverts help to control erosion. Spoil from excavations is subject to rill and gully erosion and to sloughing. Roads and landings can be protected against erosion by constructing water bars and by seeding areas that have been cut and filled. Buffer strips may be needed in areas adjacent to perennial streams to minimize siltation and maintain stream temperatures.

The slope prevents the use of wheeled and tracked equipment. High-lead or other logging systems that fully suspend the logs above the ground will damage the soil less than other systems. The risk of compaction can be reduced by using suitable harvesting methods and by harvesting when the soil is least susceptible to compaction.

Careful management of reforestation is needed to minimize competition from undesirable plants. If the site is not adequately prepared, plant competition can prevent or delay reestablishment of volunteer or planted trees. Competing weeds, brush, or trees can be controlled by spraying, cutting, or girdling.

The seedling mortality rate is increased by compaction of the surface layer and by droughtiness in the surface layer, especially on south- and southwest-facing slopes. Shading and mulching of seedlings may be required. The trees that are suitable for planting include ponderosa pine and Douglas-fir.

Trees are subject to windthrow during periods when the soil is excessively wet and winds are strong. Regeneration systems that isolate single trees or groups of trees are not practical because of the hazard of windthrow.

Some decline in forest productivity may result from fire of moderate intensity.

The understory consists mainly of common snowberry, spirea, elk sedge, pinegrass, low Oregongrape, and strawberry.

This soil can produce adequate forage for big game animals after the tree canopy is opened by logging, fire, or some other disturbance. Dense stands of timber

should be left in some areas to provide escape and thermal cover for the big game animals.

*Livestock grazing.*—The potential plant community on the Bouldrock soil is dominated by bluebunch wheatgrass, mountain big sagebrush, and buckwheat.

Bluebunch wheatgrass is the major forage-producing plant. If the site is in excellent condition, the total annual production is estimated at 1,600 pounds per acre in favorable years and 900 pounds per acre in unfavorable years. Livestock access is limited by the Rock outcrop, the slope, and the boulders on the surface.

If the condition of the site deteriorates through overgrazing, bluebunch wheatgrass loses vigor and decreases in extent. Blue wildrye, buckwheat, and mountain big sagebrush increase in extent. If deterioration continues, the extent of blue wildrye decreases and annual grasses and forbs invade the site.

Mechanical treatment for range seeding and brush control is not practical because of the slope and the boulders on the surface.

The Bouldrock soil is in the High Mountain South 16-20pz range site. The Kilmerque soil is in the Pine-Fir-Sedge woodland understory site.

**23A-Boyce silt loam, 0 to 2 percent slopes.** This deep, poorly drained soil is on flood plains. It formed in stratified, mixed alluvium. Areas are irregular in shape and are 10 to 50 acres in size. The native vegetation is mainly water-tolerant grasses, sedges, and rushes. Elevation is 2,000 to 3,600 feet. The average annual precipitation is 10 to 12 inches, the average annual air temperature is 45 to 50 degrees F, and the average frost-free period is 120 to 140 days.

Typically, the surface layer is very dark grayish brown silt loam about 4 inches thick. The next layer is very dark grayish brown, mottled silt loam about 25 inches thick. The upper 8 inches of the substratum is dark brown, mottled gravelly loamy sand. The lower part to a depth of 60 inches or more is multicolored very gravelly sand. Depth to the contrasting substratum is 20 to 40 inches.

Included in this unit are small areas of Balm soils. Also included are small areas of Cumulic Haploxerolls. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate to a depth of about 29 inches in the Boyce soil and rapid below that depth. Available water capacity is 6 to 8 inches. The effective rooting depth is limited by a seasonal high water table at a depth of 0.5 foot to 2.0 feet in spring and early

summer. Runoff is slow, and the hazard of water erosion is slight.

This unit is used mainly for pasture. It also is used for hay production, and it provides habitat for many kinds of wildlife.

*Hay and pasture.*-If this unit is used for hay and pasture, the main limitation is the seasonal high water table. Wetness limits the choice of plants and the period of cutting or grazing and increases the risk of winterkill.

Grazing during wet periods results in compaction of the surface layer, poor tilth, and excessive runoff. Conducting fieldwork during wet periods results in deterioration of tilth and destroys soil structure. As a result, it increases the runoff rate and the hazard of erosion. Compaction limits the movement of air and water in the soil and restricts the growth of roots.

Fertilizer is needed to ensure the optimum growth of grasses and legumes.

In summer irrigation is needed for the maximum production of hay. Controlled surface irrigation is a suitable method of applying water. To avoid overirrigation and the leaching of plant nutrients, applications of irrigation water should be adjusted to the available water capacity, the rate of water intake, and the needs of the crop.

Management that maintains the optimum vigor and quality of forage plants is needed. Proper stocking rates, pasture rotation, and restricted grazing during wet periods help to keep the pasture in good condition and control erosion. Periodic mowing and clipping help to maintain uniform growth and prevent selective grazing.

This soil is generally unsuited to the trees and shrubs grown as windbreaks and environmental plantings. Onsite investigation is needed to identify areas where trees and shrubs can be planted if special management is applied.

The Boyce soil is in the Wet Meadow range site.

**24D-Brannan channery silt loam, 2 to 35 percent north slopes.** This deep, well drained soil is on mountains. It formed in colluvium derived from schist and influenced by volcanic ash in the surface layer. Areas are irregular in shape and are 80 to 400 acres in size. The native vegetation is mainly conifers, shrubs, and forbs. Elevation is 4,000 to 6,000 feet. The average annual precipitation is 20 to 35 inches, the average annual air temperature is 40 to 45 degrees F, and the average frost-free period is 30 to 60 days.

Typically, the surface is covered with a mat of partially decomposed needles, twigs, and grasses about 1 inch thick. The surface layer is very dark grayish brown channery silt loam about 4 inches thick. The upper part of the subsoil is dark yellowish brown channery silt loam about 10 inches thick. The lower part

is brown very channery sandy clay loam about 14 inches thick. The substratum is brown very channery sandy clay loam. It extends to a depth of about 48 inches. The mantle of volcanic ash is 14 to 20 inches thick.

Included in this unit are small areas of Inkler soils. Also included are small areas of Crackler and Rouen soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate in the Brannan soil. Available water capacity is 4 to 7 inches. The effective rooting depth is 40 to 60 inches. Runoff is medium, and the hazard of water erosion is moderate or high.

This unit is used mainly for timber production. It also is used for livestock grazing, and it provides habitat for many kinds of wildlife.

*Woodland.*-This unit is suited to the production of Douglas-fir and grand fir. The mean site index is 50 for Douglas-fir (50-year base age) and 63 for grand fir (50-year base age). The potential production at culmination of the mean annual increment for Douglas-fir is 29 cubic feet per acre per year (2.0 cubic meters per hectare per year) in a 116-year-old, even-aged, fully stocked stand and for grand fir is 81 cubic feet per acre per year (5.7 cubic meters per hectare per year) in a 118-year-old, even-aged, fully stocked stand.

The main concerns in producing and harvesting timber are the hazard of erosion, the equipment limitation, seedling mortality, and plant competition.

Minimizing the risk of erosion is essential in areas where timber is harvested. Properly designed road drainage systems that include carefully located culverts help to control erosion. Spoil from excavations is subject to rill and gully erosion and to sloughing. Roads, landings, skid trails, and firebreaks can be protected against erosion by constructing water bars and by seeding areas that have been cut and filled. Buffer strips may be needed in areas adjacent to perennial streams to minimize siltation and maintain stream temperatures.

Using standard wheeled and tracked equipment when the soil is moist causes rutting and compaction. Displacement of the surface layer occurs most readily when the soil is dry. The risk of compaction can be reduced by using low-pressure ground equipment, laying out skid trails in advance, and harvesting timber when the soil is dry or frozen. Cable yarding systems that partially or fully suspend logs generally do less damage to the soil than conventional ground-based systems.

Careful management of reforestation is needed to minimize competition from undesirable plants. If the site is not adequately prepared, plant competition can

and is firm enough to withstand trampling by livestock.

Seeding disturbed areas to suitable plants reduces the hazard of erosion and provides forage for livestock and wildlife. Deferred grazing is needed during periods when seedlings are becoming established.

This unit can produce adequate forage for big game animals after the tree canopy is opened by logging, fire, or some other disturbance. Dense stands of timber should be left in some areas to provide escape and thermal cover for the big game animals.

The Crackler and Rouen soils are in the Mixed Fir-Princes Pine woodland understory site.

#### **40A-Cumulic Haploxerolls, 0 to 2 percent slopes.**

These deep, well drained and moderately well drained soils are on flood plains. They formed in stratified, mixed alluvium. Areas are elongated and are 25 to 80 acres in size. The native vegetation is mainly bunchgrasses and shrubs. Elevation is 2,000 to 3,600 feet. The average annual precipitation is 9 to 20 inches, the average annual air temperature is 45 to 50 degrees F, and the average frost-free period is 100 to 140 days.

Typically, the surface layer is very dark brown and very dark grayish brown loam about 11 inches thick. The next layer is very dark grayish brown sandy loam about 14 inches thick. The upper 8 inches of the substratum is dark brown loamy sand. The lower part to a depth of 60 inches or more is multicolored extremely gravelly sand. Depth to the sandy or gravelly substratum is 20 to 40 inches.

Included in this unit are small areas of Balm and Boyce soils. Also included are small areas of Riverwash. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

Permeability is moderate or moderately rapid to a depth of about 25 inches in the Cumulic Haploxerolls and very rapid below that depth. The effective rooting depth is 30 to 40 inches. Available water capacity is 4 to 6 inches. Runoff is slow, and the hazard of water erosion is slight. A seasonal high water table fluctuates between depths of 2 to 4 feet in winter and spring. The soils are occasionally flooded for brief periods in winter and spring.

This unit is used mainly for hay and pasture. It also provides habitat for many kinds of wildlife.

*Hay and pasture.*-If this unit is used for hay and pasture, the main limitation is a moderately low available water capacity.

In summer irrigation is needed for the maximum production of hay. The method used generally is governed by the crop. Controlled surface irrigation is a suitable method of applying water. Leveling helps to ensure the uniform application of water. To avoid

overirrigation and the leaching of plant nutrients, applications of irrigation water should be adjusted to the available water capacity, the rate of water intake, and the needs of the crop.

Fertilizer is needed for the maximum production of hay. Returning all crop residue to the soil and using a cropping system that includes grasses, legumes, or grass-legume mixtures help to maintain fertility and tilth.

Conducting fieldwork during wet periods results in deterioration of tilth and destroys soil structure. Grazing during wet periods results in compaction of the surface layer. Compaction limits the movement of air and water in the soil and restricts the growth of roots.

Proper stocking rates, pasture rotation, and restricted grazing during wet periods help to keep the pasture in good condition. Periodic mowing and clipping help to maintain uniform growth and prevent selective grazing.

The Cumulic Haploxerolls are in the Loamy Bottom range site.

#### **41A-Damore-Silvies silt loams, 0 to 3 percent slopes.**

This unit is on flood plains. Areas are irregular in shape and are 20 to 200 acres in size. The native vegetation is mainly water-tolerant grasses, rushes, and sedges. Elevation is 3,700 to 5,000 feet. The average annual precipitation is 12 to 25 inches, the average annual air temperature is 40 to 45 degrees F, and the average frost-free period is 50 to 90 days.

This unit is about 50 percent Damore silt loam and 35 percent Silvies silt loam. The Damore soil is in a slightly higher convex position, and the Silvies soil is in depressions. The components of this unit occur as areas so intricately intermingled that mapping them separately was not practical at the selected scale.

Included in this unit are small areas of Sumpley, Stovepipe, and Webfoot soils. Included areas make up about 15 percent of the total acreage. The percentage varies from one area to another.

The Damore soil is deep and somewhat poorly drained. It formed in mixed alluvium influenced by loess and volcanic ash in the surface layer. Typically, the surface layer is very dark brown silt loam about 12 inches thick. The next layer is very dark grayish brown silty clay loam about 10 inches thick. The upper part of the subsoil is dark yellowish brown, mottled silty clay loam about 12 inches thick. The lower part is brown and olive brown, mottled silty clay about 18 inches thick. The substratum to a depth of 60 inches or more is olive brown gravelly clay.

Permeability is moderately slow to a depth of about 34 inches in the Damore soil and slow below that depth. Available water capacity is 7 to 10 inches. The effective rooting depth is limited by a seasonal high water table at a depth of 1 to 2 feet in spring and early summer.

Agronomy Technical Note 26 - Appendix 4

Soils Data for the Eastern Oregon Phosphorus Index

| SOIL<br>SURVEY<br>AREA NO. | SOIL SURVEY AREA<br>NAME | MAP UNIT<br>SYMBOL | COMPONENT NAME | COMP.<br>PCT. | HYD.<br>GROUP | SLOPE<br>LOW<br>(%) | SLOPE<br>HIGH<br>(%) | P INDEX<br>RUNOFF<br>CLASS | SURFACE<br>TEXTURE | Kw   | Kf   |
|----------------------------|--------------------------|--------------------|----------------|---------------|---------------|---------------------|----------------------|----------------------------|--------------------|------|------|
| OR604                      | Baker                    | 4B                 | APPLEGATE      | 85            | C             | 2                   | 7                    | medium                     | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 4C                 | APPLEGATE      | 85            | C             | 7                   | 15                   | high                       | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 11A                | BAKER          | 85            | C             | 0                   | 2                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 11B                | BAKER          | 85            | C             | 2                   | 7                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 12A                | BAKER          | 85            | C             | 0                   | 2                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 12B                | BAKER          | 85            | C             | 2                   | 7                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 13A                | BALDOCK        | 85            | D             | 0                   | 2                    | medium                     | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 15A                | BALM           | 85            | D             | 0                   | 3                    | medium                     | L                  | 0.28 | 0.28 |
| OR604                      | Baker                    | 16B                | BARNARD        | 85            | C             | 2                   | 7                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 16C                | BARNARD        | 85            | C             | 7                   | 12                   | high                       | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 16D                | BARNARD        | 85            | C             | 12                  | 20                   | high                       | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 17C                | BARNARD        | 85            | C             | 7                   | 20                   | high                       | CB-SIL             | 0.32 | 0.43 |
| OR604                      | Baker                    | 18B                | BENDERLY       | 85            | A             | 0                   | 7                    | negligible                 | GR-FSL             | 0.15 | 0.28 |
| OR604                      | Baker                    | 23A                | BOYCE          | 85            | D             | 0                   | 2                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 25C                | BROWNEE        | 60            | B             | 2                   | 12                   | medium                     | L                  | 0.32 | 0.32 |
| OR604                      | Baker                    | 26D                | BROWNEE        | 50            | B             | 12                  | 35                   | high                       | L                  | 0.32 | 0.32 |
| OR604                      | Baker                    | 27C                | BROWNSCOMBE    | 85            | C             | 2                   | 12                   | high                       | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 31A                | BURKEMONT      | 85            | C             | 0                   | 2                    | medium                     | SICL               | 0.43 | 0.43 |
| OR604                      | Baker                    | 32A                | BURNTRIVER     | 85            | B             | 0                   | 2                    | low                        | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 35A                | CATHERINE      | 85            | C             | 0                   | 2                    | medium                     | SIL                | 0.28 | 0.28 |
| OR604                      | Baker                    | 36C                | KEATING        | 40            | C             | 2                   | 12                   | high                       | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 41A                | DAMORE         | 50            | C             | 0                   | 3                    | medium                     | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 50C                | ENCINA         | 85            | B             | 2                   | 12                   | medium                     | GR-SIL             | 0.28 | 0.32 |
| OR604                      | Baker                    | 54B                | GOODRICH       | 85            | B             | 0                   | 3                    | low                        | GR-L               | 0.28 | 0.32 |
| OR604                      | Baker                    | 55B                | GOODRICH       | 50            | B             | 0                   | 7                    | low                        | GR-L               | 0.28 | 0.32 |
| OR604                      | Baker                    | 55B                | BENDERLY       | 35            | A             | 0                   | 7                    | negligible                 | GR-FSL             | 0.15 | 0.28 |
| OR604                      | Baker                    | 63A                | HALFWAY        | 85            | D             | 0                   | 3                    | medium                     | C                  | 0.17 | 0.17 |
| OR604                      | Baker                    | 70A                | HERSHAL        | 85            | D             | 0                   | 2                    | medium                     | SIL                | 0.28 | 0.28 |
| OR604                      | Baker                    | 81C                | IMMIG          | 85            | C             | 2                   | 12                   | high                       | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 84D                | JETT           | 85            | B             | 0                   | 3                    | low                        | SIL                | 0.24 | 0.24 |
| OR604                      | Baker                    | 90B                | LADD           | 85            | B             | 2                   | 7                    | low                        | L                  | 0.32 | 0.32 |
| OR604                      | Baker                    | 91A                | LA GRANDE      | 85            | C             | 0                   | 3                    | medium                     | SIL                | 0.28 | 0.28 |
| OR604                      | Baker                    | 92A                | LANGRELL       | 85            | B             | 0                   | 3                    | low                        | GR-L               | 0.17 | 0.28 |
| OR604                      | Baker                    | 93A                | LANGRELL       | 85            | B             | 0                   | 3                    | low                        | CBV-L              | 0.17 | 0.37 |
| OR604                      | Baker                    | 105C               | MARACK         | 85            | C             | 2                   | 12                   | high                       | GR-SICL            | 0.28 | 0.43 |
| OR604                      | Baker                    | 107C               | MARACK         | 50            | C             | 2                   | 12                   | high                       | GR-SICL            | 0.28 | 0.43 |
| OR604                      | Baker                    | 107C               | MARACK         | 40            | C             | 2                   | 12                   | high                       | SIL                | 0.43 | 0.43 |
| OR604                      | Baker                    | 114C               | NORTH POWDER   | 85            | C             | 2                   | 12                   | high                       | L                  | 0.24 | 0.24 |
| OR604                      | Baker                    | 126A               | POWVAL         | 85            | B             | 0                   | 3                    | low                        | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 127A               | POWVAL         | 85            | B             | 0                   | 3                    | low                        | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 129B               | RASTUS         | 85            | C             | 1                   | 7                    | medium                     | GRV-L              | 0.20 | 0.32 |
| OR604                      | Baker                    | 131C               | RIDLEY         | 50            | C             | 2                   | 12                   | high                       | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 131C               | KEATING        | 40            | C             | 2                   | 12                   | high                       | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 159A               | STANFLOW       | 50            | C             | 0                   | 2                    | medium                     | SIL                | 0.43 | 0.43 |
| OR604                      | Baker                    | 162A               | SUMPLEY        | 50            | C             | 0                   | 3                    | medium                     | SIL                | 0.37 | 0.37 |
| OR604                      | Baker                    | 169C               | UKIAH          | 85            | D             | 2                   | 12                   | high                       | SICL               | 0.32 | 0.32 |
| OR604                      | Baker                    | 169D               | UKIAH          | 85            | D             | 12                  | 20                   | very high                  | SICL               | 0.32 | 0.32 |
| OR604                      | Baker                    | 171B               | VIRTUE         | 85            | C             | 2                   | 7                    | medium                     | SIL                | 0.32 | 0.32 |
| OR604                      | Baker                    | 172B               | VIRTUE         | 85            | C             | 2                   | 7                    | medium                     | GRV-SIL            | 0.28 | 0.32 |
| OR604                      | Baker                    | 175A               | WINGDALE       | 85            | D             | 0                   | 2                    | medium                     | SIL                | 0.28 | 0.28 |
| OR604                      | Baker                    | 176A               | WINGVILLE      | 85            | D             | 0                   | 2                    | medium                     | SIL                | 0.28 | 0.28 |

Data is from the NASIS database as of 7/2001

**ANIMAL WASTE MANAGEMENT PLAN  
MINIMUM REQUIRED ELEMENT**

ANIMAL MORTALITY

Management of Animal Mortalities for: **Randall Ranch Feedlot**  
NAME OF OPERATION

Animal mortalities will be disposed of in a manner that will comply with local, state and federal regulations. Please mark and describe the method(s) of animal mortality management used on this operation:

☐ REMOVAL SERVICE: \_\_\_\_\_

☐ COMPOSTED: \_\_\_\_\_

☐ INCINERATED: \_\_\_\_\_

☒ BURIED: FOLLOWING STATE GUIDELINE

☐ OTHER: \_\_\_\_\_

Signature of Legally Authorized Representative: \_\_\_\_\_

Print Name: \_\_\_\_\_

Date: \_\_\_\_\_

Rocky Randall  
Rocky Randall 7-10-08

## **Record Keeping and Reporting Requirements**

### **Testing-Monitoring**

**Include the protocol for testing manure, litter and process waste**

**Include the protocol for testing and measuring crop nutrient removals**

**Include the protocol for soil testing to evaluate nutrient application  
and crop uptake**

### **Record Keeping- Include the following**

**Date and amount of manure, litter and process waste applied by field.  
Calculate N & P applied.**

**Manure, litter and process waste volume exported**

### **Reporting to Oregon Department of Agriculture**

**Any discharge within 24 hours**

**Amount of manure, litter and process waste applied annually**

**Amount of manure, litter and process waste exported annually**

**ANIMAL WASTE MANAGEMENT PLAN  
MINIMUM REQUIRED ELEMENT**

RECORD KEEPING AND REPORTING TO OREGON DEPARTMENT OF  
AGRICULTURE

RECORD KEEPING:

- a) Applications of manure, litter and process waste will be kept, including the date and the amount of N and P applied during each application.
- b) Records of exporting manure, litter and process waste will also be kept.

REPORTING TO OREGON DEPARTMENT OF AGRICULTURE (ODA):

- a) Any discharge will be reported orally to ODA within 24 hours. Within 5 days, a written statement describing this discharge will also be submitted to ODA.
- b) The amount of manure, litter and process waste applied will be reported annually.
- c) The amount of manure, litter and process waste exported will be reported annually.

Signature of Legally Authorized Representative: \_\_\_\_\_

*Rocky Randall*

Print Name: \_\_\_\_\_

*Rocky Randall*

Date: \_\_\_\_\_

*7-10-08*

### **Record Keeping and Reporting:**

Soil samples will be taken in each field, once every five years. Whenever exporting waste off site, a manure samples will be taken and provided to the export recipient. Copies of the manure samples will also be kept on file as a part of this Animal Waste Management Plan. Protocol for sampling and testing soil, manure, and crops are included in this Animal Waste Management Plan.

Randall Ranch Feedlot records date and amount of manure applied to each field. Randall Ranch Feedlot will also record the date and amount of any waste exported off site. Randall Ranch Feedlot will report any discharge within 24 hours to the Oregon Department Of Agriculture. Annual reports will include the amount of manure applied annually and will be submitted each year.

## ODA Soil Sampling Standard Methodology

### March, 2001

This document is intended to describe a standard procedure for collecting, storing, and shipping soil samples collected by ODA staff and/or contractors. All ODA staff involved in soil sampling should have received training in Departmental protocols for soil sampling. The procedures described are intended to be used for non-hazardous samples that are not going to be analyzed for volatile constituents. Soil samples collected with the methods described can not be considered undisturbed samples.

#### Considerations for Choosing Laboratory Analyses

Before conducting any soil sampling, first decide what parameters you will be looking for and how they should be analyzed. This is important for choosing an appropriate analytical laboratory, for budgeting, and for knowing how soon the laboratory must receive your samples. Most of the sampling done by CAFO/NRD staff involves looking for nitrogen compounds, phosphorus compounds, potassium compounds, bacteria, and organic matter or total organic carbon. This section will focus on the analytical techniques for these compounds, and how to decide which chemical species to look for. If you are planning on analyzing for other compounds, consult with the NRD technical staff.

*Nitrogen compounds:* The nitrogen compounds we are usually concerned with are nitrate ( $\text{NO}_3$ ), nitrite ( $\text{NO}_2$ ), ammonia ( $\text{NH}_3$ ), ammonium ( $\text{NH}_4$ ), and total Kjeldahl nitrogen (organic nitrogen compounds, typically  $\text{NH}_2$ ). Typically, the older the manure source, the more likely that the nitrogen will be in the form of nitrate. Manure starts as being mostly  $\text{NH}_2$  to  $\text{NH}_4$ , and eventually oxidizes to  $\text{NO}_2$  and  $\text{NO}_3$ .

Analysis of total Kjeldahl nitrogen (TKN) is standardized, so telling a laboratory you want a TKN analysis will get you about the same thing every time. The same is true for ammonia and ammonium. However for nitrate and nitrite, there are two widely used methods to choose from. EPA Method 300, which is an ion chromatography method, and EPA Method 353.2, which uses cadmium reduction. These analyses report nitrate and nitrite combined, or separately. You can specify how you'd like the results presented. However, if you do want nitrite reported separate from nitrate, then the sample must be analyzed (using either method) within 48 hours after collection. EPA Method 300 has a 48 hour holding time whether or not speciation of  $\text{NO}_2/\text{NO}_3$  is requested, so usually EPA Method 353.2 is the better choice for nitrate/nitrite analyses.

*Phosphorus compounds:* In most cases, we are concerned with all phosphorus compounds that are not tied up with silicate minerals (e.g., apatite). However, standard total phosphorus analyses use an acid digestion, which will liberate phosphorus tied up in minerals. Because of this, the preferred method is AOAC Official Method 977.01. This method uses a water extraction of phosphorus, so that mineralized forms are not brought into solution. If the laboratory can not do this method, then request a weak acid extraction, which would use citric or acetic acid. Make sure the laboratory can supply a reference for any alternative method they propose, other than AOAC Official Method 977.01. If you are sure that there will be no significant mineral phosphorus component in the sample, then the laboratory can use a more traditional total

phosphorus (TP) analysis. The NRD hydrogeologist or hydrologist can give you advice on whether there is a potential for the presence of mineral phosphorus.

*Potassium compounds:* Sampling and analysis for potassium compounds has a lot in common with analyzing for phosphorus compounds. Standard analyses also use an acid extraction, which can liberate silicate-bound potassium. Generally we want to detect all water soluble forms of potassium. To avoid sampling mineral forms of potassium, request a STLC (soluble threshold limit test) extraction analysis, instead of EPA Method 3010. STLC is routinely done for toxic metals, but can also be performed successfully for potassium.

*Bacteria sampling:* Appropriate bacteria sampling and analysis is dependant mostly on getting the sample to the laboratory immediately. For identifying issues relating to manure, either fecal coliform or E. coli sampling is valid, but in both cases the samples should be analyzed by the laboratory the same day they are collected. Make sure the lab can give you a population count of the bacteria, a presence/absence analysis is usually not meaningful for the purposes of our investigation. Also, make sure the lab can analyze soil samples for bacteria - it is not commonly as available as analysis of water samples.

### **Hand Auger Sampling**

Hand auger sampling is done by advancing the auger to approximately six inches below the desired depth of sampling, and then removing soil from the central portion of the auger barrel. The soil from the central part of the barrel should be used as the sample, because it is less likely to have been contaminated from material sloughing off the walls of the boring. Ideally, the sample should be placed in a laboratory supplied container, however new sealable plastic bags can be used if laboratory containers are not available. Whenever possible, take two samples at each sampling location. These should be labelled as 'A' and 'B' samples, so that you have a back up sample if something happens to one of them, or if you want to augment regular quality assurance/quality control procedures. Both 'A' and 'B' samples should be sent to the laboratory, but not necessarily analyzed. This is discussed further in the Sample Handling and Documentation section of this methodology.

Always backfill hand augered borings after sampling is finished. Do not advance hand augered borings into groundwater (including perched water), unless groundwater samples are needed.

### **Trowel or Shovel Sampling**

Trowels, shovels, and other implements can also be used to obtain soil samples. Usually these are not very efficient for sampling below about one foot, and they are not accurate for sampling at a designed depth. They are appropriate for shallow soil sampling. When using these types of implements, follow the decontamination procedures described below. Remove all soil from the excavated area before obtaining a sample, so that the sample will be representative of the desired area.

### **Equipment Decontamination (Decon)**

Decontamination is important to prevent false positive or erroneous analytical results for soil sampling. Generally decontamination involves removing as much of the soil from the sampling equipment as possible before using the equipment on another sample. Usually this can be done with tap water, an approved detergent, a brush, two buckets, plastic sheeting or some other portable clean surface, and deionized (or distilled) water in a spray bottle. Sampling equipment should be rinsed with deionized water after being washed and scrubbed with a detergent solution, especially if any metals will be the sample analytes. The scrub brush size must be appropriate to clean all surfaces that may contact samples, including the barrel of the auger. Sampling equipment should be decontaminated before each use, even if the equipment has been in clean storage. Sampling equipment should also be decontaminated before replacing equipment into the field vehicle between sample points and at the end of the day. Choose an area to do decon in advance, being careful to avoid areas where small spills of detergent or wash water would be a problem. Use plastic sheeting or other portable clean surface for holding decontaminated equipment between uses. Decontamination methods should be appropriate for the planned analytes. For example, if the analysis will be for sodium, then you should not use a detergent containing sodium carbonate. Many common detergents contain either sodium carbonate or some type of phosphorus compound, so be careful not to use these when sodium or phosphorus are the analytes. Other commercially available detergents - like Liquinox - should be used instead. If there are any questions as to the appropriateness of detergent, contact the appropriate ODA technical staff for assistance.

### **Sampling Strategies**

Various methods can be used to determine how many samples to take, and where to take them. Economic limitations must also be considered, especially when the intended chemical analyses will be expensive. Most sampling schemes employed by ODA staff will be simple "Judgemental" schemes, where there will be some visible or olfactory evidence to justify sampling. Statistically valid sampling schemes are discussed in two EPA documents, "Preparation of Soil Sampling Protocols: Sampling Techniques and Strategies" and "Site Characterization for Subsurface Remediation." Comprehensive statistically relevant sampling plans should be peer-reviewed by ODA technical staff.

### **Sample Handling and Documentation**

Sterile, clean sampling containers should be obtained from the lab complete with any specific instructions relating to the planned analytes. Make sure to follow the laboratory's guidance on holding times and quality assurance/quality control for each planned analyte.

After obtaining a sample, it should be labelled immediately to reduce the possibility of misidentification. The label should include the sample number (including 'A' and 'B' designations), date and time of collection, the collector's initials, and some name reference to the geographic location of the sampling. This information should also go into field notes taken during the sampling. The sample should then be placed in a chilled container, preferably with "blue ice" as opposed to wet ice. If wet ice is used, seal the samples in closeable plastic bags (providing a double seal against moisture) before storing. A chain-of-custody form must

accompany all samples collected, and must be signed by all parties who handle the samples. This form is needed to document where the samples have been and who has handled them. Information from the sample label should be repeated on a chain-of-custody form, along with laboratory instructions. Make sure to indicate which samples you want analyzed - typically you will not have the 'B' samples analyzed immediately, if at all. These are usually kept as a back-up. Ideally, the samples should be hand-delivered to a laboratory, however in many instances they will have to be shipped. Most of the time companies like UPS and Federal Excess will not sign chain-of-custody forms. In this case, provide a signed seal over every access to the shipping container. Make sure the laboratory receiving the samples documents the condition of the seal.

Along with information specific to each sample, field logs should contain a detailed description of where and when each sample was taken. This description should include sample depth, sampling equipment used, sampling location justification, approximate distances from reference points (this is usually best accomplished with a sketch), whether the samples had any obvious odors or discoloration, and what weather conditions were like during the field work. Sampling location justification should include a description of the area where the sample was taken, including any discoloration or obvious odors. Photographs of the sampling locations and their surroundings should also be taken.

## Appendix A: Soil Sampling Procedure

The following procedure may be used as a step-by-step soil sampling procedure. If it should become necessary to deviate from this procedure in a way that may invalidate the sampling results, contact appropriate ODA technical staff for recommendations on modifications to the procedure.

1. Before going to the field location, inventory sampling equipment to ensure all necessary equipment is available (a sample list is available in Appendix B).
2. At the field location, select appropriate location for decontamination station. Ideally, this location will be proximal to sampling locations, but will have a very low risk of becoming contaminated due to site conditions (e.g., wind, traffic, etc.).
3. Set up decontamination station. Be careful not to contaminate the station. This area will allow you to store decontaminated equipment until ready for use.
  - a. Fill sprayer with demineralized (deionized) water.
  - b. Mix soap solution (Liquinox® or other approved soap) as directed by the label.
  - c. If bacteria sampling will occur, prepare the sterilizing agent as directed on the label or in Appendix E.
4. Decide why sampling will occur, and select appropriate analytes (see Appendix C).
5. Map out the location of the sampling sites, showing their locations relative to permanent landmarks and/or GPS coordinates. If you are doing sampling to establish an area-wide soil condition assessment (e.g., finding out if land application of manure has exceeded agronomic rates throughout a field), then state how many samples per unit area, and draw a dimensionless map of their locations.
6. Perform initial decontamination of equipment for appropriate analytes (i.e., you do not need to disinfect the equipment if bacteria will not be analyzed).
7. Decontamination procedure:
  - a. Clean as much soil off the auger as possible utilizing mechanical agitation (e.g., dry brush, garden spade, tapping barrel lightly on rock, etc.).
  - b. Use tap water to remove more dirt if desired.
  - c. Scrub sampling equipment with soapy water (including all areas where the equipment is touched by the technician). Ensure scrub brushes fit in all orifices and cracks of equipment.
  - d. Perform tap water rinse.
  - e. Shake to remove excess water.
  - f. If sampling for bacteria, apply sterilizing agent and satisfy contact times described on label or in department approved procedures.
  - g. Perform demineralized water rinse, then shake off excess water.

- h. Place decontaminated equipment on a clean (i.e., area known to be free of contamination) surface until equipment is to be used.
8. To collect a soil sample:
- a. Auger or dig to six inches above the desired sample interval.
  - b. Decontaminate the equipment used, and put on clean gloves.
  - c. Auger or dig to collect the sample.
  - d. Adjacent to the decontamination station, place the sample in a laboratory supplied or approved sampling container. Split the sample for all analytes except bacteria.
  - e. Once the sample is sealed (for additional security, seal sample containers with adhesive that bears your signature), label the sample. Information should include sample number (including A or B for split samples), sample technician, date, and farm name. Your field log should include this information, plus complete location descriptions and time of sampling. If storage on ice is required, place sample containers in sealed zip-lock bags.
  - f. Place the sample in the shipping or handling container. Ensure laboratory recommendations are followed (e.g., ice).
  - g. If another sample is to be taken from the same hole, return to step 6 and continue. If sampling is completed for this hole, decontaminate sampling equipment.
9. If other holes are to be sampled, return to step 6 and continue. If sampling is completed for this operation, decontaminate and store sampling equipment using the decontamination procedure. If equipment has not been allowed to air dry before storage, ensure the storage area is well ventilated, and that equipment can thoroughly dry in this location. (Note: Ensure contaminated equipment is never stored in your clean equipment storage area of your vehicle. If this occurs, decontaminate this area and allow it to air dry before returning sample equipment.)
10. Once sampling is complete, clean up the decontamination station and backfill the auger hole.
- a. For disposable equipment, decontaminate any gross contamination before cleaning re-usable equipment.
  - b. For re-usable equipment, ensure that the outsides of the containers are decontaminated when necessary. The insides of the containers need only be cleaned using subsequent steps of the decontamination procedure (e.g., the soapy water bucket should be rinsed with tap-water, washed with any disinfectant used, rinsed with demineralized water, and allowed to air dry. The tap-water equipment need only be washed with any disinfect used, rinsed with demineralized water, and allowed to air dry. And so on.).
  - c. Unless label restrictions indicate otherwise, all fluids may be safely disposed of by pouring them onto the land surface (preferably in a grassy area where runoff to a drainage is unlikely). Most fluids may also be poured down drains connected to sanitary sewers or septic systems. DO NOT POUR DISINFECTANTS INTO

SEPTIC SYSTEMS. Septic systems rely on beneficial bacteria for proper operation.

- d. If any equipment is not dry when placed in storage, ensure it is placed in a well ventilated storage area in the vehicle.
- e. For disposable equipment:
  - i. Remove excess water.
  - ii. Place all disposable items in the center of the decontamination pad (i.e. the plastic sheeting).
  - iii. Remove gloves and place in center.
  - iv. Making sure you do not touch the upper surface of the decontamination pad (the bottom has not been impacted by sampling), fold the pad over onto itself, and place the entire assembly into a large garbage bag. Seal the garbage bag, and dispose of in any trash receptacle. If necessary, the sealed sack allows you to transport the trash in your vehicle without contaminating your "clean" equipment storage.
- f. When backfilling, make sure the soil put into the hole is compacted as much as possible.

#### **Appendix B: Sample Equipment List**

The following is an example of a typical equipment list for soil sampling. Personal preference may result in substitution or addition of equipment.

1. Hand auger with appropriate extensions and barrels.
2. Gardening trowel.
3. Shovel.
4. Lab supplied sample (wide-mouth) jars.
5. Adhesive sample labels that allow assignment of sample number, date, time, person conducting sampling, and farm name.
6. Chain of custody forms that contain sufficient blocks to establish that hold-time criteria are not exceeded.
7. One or more buckets for wash water.
8. Round scrub brush that fits into auger barrels.
9. Liquinox soap (or other soap that meets chemical criteria).

10. Demineralized water in spray rig for final rinse.
11. Chlorine bleach or other effective disinfectant.
12. Plastic sheeting to act as clean area (may want to include rocks to hold sheeting down in windy conditions).
13. Equipment that allows adequate field location of sample sites (e.g., GPS unit, compass, tape measure).
14. Camera.
15. Write-in-the-Rain notebook with pen that writes in the rain on both labels and the notebook.
16. Trash sacks for disposal of used supplies.
17. Ice chest and ice for sample preservation.
18. Security seals for containers to be shipped.
19. Box of latex gloves.

### Appendix C: Soil Sampling Depth Matrix

Soil sampling occurs primarily for one of three reasons: 1) to determine that wastes are being applied at agronomic rates; 2) to ascertain whether or not deep leaching of waste constituents are occurring; and 3) to determine if wastes have run off to an area where wastes are prohibited. The following table provides guidance on sampling depth and pollutants of concern.

| REASON FOR SAMPLING                     | SAMPLE DEPTHS                                                                                                                                        | ANALYTES                                                                                                                                                                                              |
|-----------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Determination of agronomic application. | 6 inch sample                                                                                                                                        | Mineralizable N test or TKN, ammonium, and nitrate; ortho-phosphorus; and potassium.                                                                                                                  |
| Suspicion of deep leaching.             | 1 foot, 3 feet, and deepest rooting depth if significantly different than 3 feet.                                                                    | Ammonium, nitrate+nitrite, ortho-phosphorus, and potassium.                                                                                                                                           |
| Wastes suspected in prohibited area.    | Collect visibly impacted soils. If soils are not visibly impacted, collect 6 inch sample. If deep leaching is suspected, also follow above guidance. | Use the determination of agronomic application analytes above for 6 inch and shallower samples, plus add total organic carbon. For deeper samples use the analytes above for suspected deep leaching. |

Normally, bacteria analysis of soils will not be required. If soil areas are periodically subject to concentrated flow that may result in suspension of sediment in a water column, bacteria analysis may be appropriate. For unusual sampling situations, contact appropriate ODA technical staff for advice on sampling methodology.

## **Appendix D: Recommended Analytic Methods**

The following is a list of the recommended methods of analysis for **soil samples only**. Some of the methods discussed can be used for water samples, but the rationale used in this document for choosing an analytical method is meant only for soil samples.

*Nitrogen compounds:* Analyses for total Kjeldahl nitrogen (TKN), ammonia, and ammonium are mostly standardized, so any method a reputable lab chooses should be fine. Nitrate and nitrite, have two widely used methods to choose from. EPA Method 300, which is an ion chromatography method, and EPA Method 353.2, which uses cadmium reduction. These analyses report nitrate and nitrite combined, or separately. You can specify how you'd like the results presented. However, if you do want nitrite reported separate from nitrate, then the sample must be analyzed (using either method) within 48 hours after collection. EPA Method 300 has a 48 hour holding time whether or not speciation of NO<sub>2</sub>/NO<sub>3</sub> is requested, so usually EPA Method 353.2 is the better choice for nitrate/nitrite analyses.

*Phosphorus compounds:* In most cases, we are concerned with all phosphorus compounds that are not tied up with silicate minerals (e.g., apatite). Use AOAC Official Method 977.01, which is a water extraction of phosphorus, so that mineralized forms are not brought into solution. If the laboratory can not do this method, then request a weak acid extraction, which would use citric or acetic acid. Make sure the laboratory can supply a reference for any alternative method they propose, other than AOAC Official Method 977.01. If you are sure that there will be no significant mineral phosphorus component in the sample, then the laboratory can use a more traditional total phosphorus (TP) analysis. Analyses for phosphate (PO<sub>4</sub>) are fairly standardized, so any method a reputable lab chooses should be fine.

*Potassium compounds:* Sampling and analysis for potassium compounds has a lot in common with analyzing for phosphorus compounds. Standard analyses also use an acid extraction, which can liberate silicate-bound potassium. Generally we want to detect all water soluble forms of potassium. To avoid sampling mineral forms of potassium, request a STLC (soluble threshold limit test) extraction analysis, instead of EPA Method 3010.

*Bacteria sampling:* Appropriate bacteria sampling and analysis is dependant mostly on getting the sample to the laboratory immediately. For identifying issues relating to manure, either fecal coliform or E. coli sampling is valid, but in both cases the samples should be analyzed by the laboratory the same day they are collected. Make sure the lab can give you a population count of the bacteria, a presence/absence analysis is usually not meaningful for the purposes of our investigation. Also, make sure the lab can analyze soil samples for bacteria - it is not commonly as available as analysis of water samples.

## **Appendix E: Recommended Disinfectants**

All disinfectants should be used in accordance with the label instructions. General disinfectants (e.g., chlorine bleach) may also be used with concentrations and contact times as specified in this appendix. The only other disinfectant currently recommended for use is Virkon S, which is also used by the Animal Health division.

## APPENDIX E - ANIMAL WASTE SAMPLING

Animal waste analysis is a key component of nutrient management. Complete analyses provide critical information about the animal waste composition, including pH and nutrient content. Actual nutrient content of animal waste varies with the type of animal, feed, storage system, and method of animal waste application. You should sample animal waste stored on site each time it is to be removed (for land application on or off site). Sample daily spread operations (if you land-apply daily) several times throughout the year to obtain a good estimate of nutrient content.

### Description

Animal waste sampling is relatively simple, but must be done properly for reliable results. The sampling method differs based on the type of animal waste you generate at your farm (e.g., liquid, semi-solid, solid). Animal waste sampling generally consists of two to seven steps, depending on the type of animal waste. Although the number of steps varies based on the physical state of the animal waste, all of the methods rely on collecting a representative animal waste sample for analysis. Where bedding is collected with the animal waste, include both bedding and animal waste in the sample. Also, conduct sampling as close to the time of land application as possible. Specific techniques for gathering poultry litter, liquid animal waste, semi-solid animal waste, and solid animal waste samples are described below; you can use these to help develop sampling procedures at your farm. Remember that you should sample and analyze all animal waste at your farm. Work with your state and local agricultural Cooperative Extension Offices to ensure that you develop the proper procedures for your conditions and animal waste management methods.


Before sampling, know where the samples are to be shipped, how to pack and ship the sample, and what to use as sample containers. Many laboratories will furnish the proper sample containers for a small charge. Samples should never be collected and shipped in glass bottles, and they should be shipped on wet ice unless otherwise instructed by the laboratory. Contact your state or local agricultural Cooperative Extension Office for a list of laboratories that can perform your analyses. You should also wear gloves at all times, to protect yourself and the sample from contamination.

The test should analyze for such parameters as percentage of dry matter, ammonium-nitrogen, total-nitrogen, phosphorus (P or  $P_2O_5$ ), and potassium (K or  $K_2O$ ). Request results in the same units as your calibrated animal waste application system (see Appendix J for more information about calibrating animal waste spreaders and irrigators). For example, if your animal waste application is measured in tons per acre, request that your analysis be reported as pounds of nutrient per ton of animal waste.

### Instructions for Collecting Poultry Litter Samples

Poultry litter is a mixture of poultry animal waste and the bedding (e.g., sawdust or rice hull) from houses used to raise broilers, turkeys, and other birds. You will need a clean 5-gallon bucket, a narrow, square-ended spade (or a soil spade), and a 1-quart plastic freezer bag to collect and store your sample. The five steps to collecting a representative poultry litter sample are described below.

*Step 1:* Mentally divide the poultry house into three zones of equal size. Within each zone, you'll take six cores (i.e., samples) as shown in the diagram below.



*Step 2:* Take the first core within 1 foot of the feed line using your spade. Clear a small trench the width of the spade to the depth of the litter and remove a 1-inch slice, making sure to get equal amounts of litter from all depths. Empty the sample into your bucket.

*Step 3:* Repeat the process, gathering six cores from each zone, taking your last core within each zone within 1 foot of the water line. Walk the length of the building in each zone in a zigzag pattern taking cores with the spade at random points along your path (as shown in the diagram above). Take a representative number of cores under feeders and waterers. If the bucket becomes full before all 18 samples are taken, dump the contents onto a plastic sheet and continue sampling.

*Step 4:* After collecting samples from all three zones, crumble and thoroughly mix all of the litter in the bucket. It may be easier to pour the material onto a piece of plastic, or plywood, or into a wheelbarrow to facilitate mixing. Thorough mixing is critical to ensure that the analyzed sample is representative of the entire house.

*Step 5:* After the litter is well mixed, fill your plastic freezer bag with a subsample (i.e., a small sample) from your composite. Fill the bag only two-thirds full and squeeze the air out before sealing. Keep the sample cool (on ice if possible) until it is shipped.

#### Instructions for Collecting Liquid Animal Waste Samples

Liquid animal waste is typically stored in tanks, lagoons, or ponds. For tanks, collect only one sample, but collect several subsamples of liquid animal waste to get a representative sample from lagoons and ponds. You will need a clean 5-gallon bucket, a plastic cup, wire, and a long pole to collect liquid animal waste samples from lagoons and ponds. Sample containers are required to collect liquid animal waste samples from all sources. The two steps to collect a representative liquid animal waste sample are described below.

*Step 1:* For lagoons and ponds, collect several samples from around the shore of the lagoon or pond and mix them together in a clean 5-gallon bucket. You can collect the samples by wiring a plastic cup to the end of a long pole. When taking the sample, turn the cup upside down and push it a few feet below the surface. Then turn the cup right side up and pull out the sample.

If you store your liquid waste in tanks, your tanks must be well agitated before sampling. Often the only practical time to do this is as you are pumping the animal waste into your spreader.

*Step 2:* Fill a sample container with your sample, making sure to leave 2 inches of air space. Tightly seal the container and keep cool (on ice if possible) until it is shipped.

### Instructions for Collecting Semi-Solid Animal Waste Samples

Collecting a representative sample of semi-solid animal waste is best done using a simple sampling device. You will need a 2-inch PVC pipe, nylon rope, a rubber ball, a dowel, a clean 5-gallon bucket, and sample containers. The seven steps to collecting a representative semi-solid animal waste sample are described below.

*Step 1:* Get a length of 2-inch PVC pipe long enough to reach well into your animal waste storage facility. Cut a notch 2 inches long and 1/4 inch wide at one end of the pipe. Cut a length of nylon rope 2 feet longer than the PVC pipe and tie a knot at one end. Drill a hole through a 2.5 inch rubber ball. Thread the rope through the ball until it is snug against the end knot. Tie a second knot to hold the ball at the end of the rope. Thread the rope through the PVC pipe and pull it until the ball plugs the end of the pipe. Slip your end of the rope into the notch and tie a knot; this will create a "latch" to keep the pipe sealed after you collect the sample. Tie a short dowel to the free end of the rope to serve as a hand grip. Cut a length of 1-inch PVC pipe and seal one end. Use this pipe to push samples out of the tube.

*Step 2:* With the ball sealing the end of the pipe, push the pipe through the top layer of animal waste to form a sample hole.

*Step 3:* Release the rope from the notch so that the ball dangles freely from the end of the pipe. Push the pipe into the sample hole in the animal waste crust. Make sure the ball does not block the pipe opening.


*Step 4:* Ease the pipe back slightly and pull the rope until the ball seals the end of the pipe. Slip the rope in the notch to anchor the ball in place and withdraw the pipe.

*Step 5:* Pour the sample into a clean 5-gallon bucket. You may need the 1-inch PVC pipe to force the sample from the pipe. Two people will need to operate a long pipe. To avoid backwash, keep the bottom of the pipe lower than your end.

*Step 6:* Repeat this process at several locations around the pit.

*Step 7:* Mix samples thoroughly in the bucket, then fill your sample container with the mix, leaving 2 inches of air space. Tightly seal the container and keep the sample cool (on ice if possible) until it is shipped.

A diagram of the sampling apparatus is shown below.



Sample Apparatus for Semi-Solid Animal Waste

### Instructions for Collecting Solid Animal waste

Collecting a representative sample of solid animal waste is best done using a simple sampling device. You will need thin-walled metal tubing (1-inch diameter), a drill, a dowel or short metal rod, a clean 5-gallon bucket, and sample containers. The four steps to collecting a representative solid animal waste sample are described below.

*Step 1:* Cut a 3-foot length of thin-walled metal tubing and sharpen the bottom edge. Near one end, drill

through the tubing and slide in a dowel or short metal rod to make a handle. Cut a 4-foot length of broomstick to force samples from the tube.

*Step 2:* Push and twist the tubing all of the way into the animal waste pile. Use the broomstick to push the animal waste into a clean 5-gallon bucket.

*Step 3:* Repeat Step 2 at several random locations around the pile. It is recommended that the more samples the better, so try to get at least 20 samples.

*Step 4:* Mix samples in the 5-gallon bucket, and fill the sample container with the mix, leaving 2 inches of air space. Tightly seal the container and keep the sample cool (on ice if possible) until it is shipped.

### **Animal Waste Sample Analyses**

Contact your state or local agricultural Cooperative Extension Office for a list of available laboratories that can analyze your animal waste samples. Some Cooperative Extension Offices may even provide free analysis (e.g., in Maryland).

Label, package, and ship your samples to your contracted laboratory. The laboratory should be able to provide their proper protocol for packaging and shipping samples.

Your animal waste sample is typically analyzed for the following constituents:

- Nitrogen;
- Phosphorus;
- Potassium;
- pH;
- Moisture content;
- Calcium;
- Manganese;
- Magnesium;
- Sulfur;
- Zinc; and
- Copper.

The first step in interpreting analytical results of an animal waste test is to check the units used to report the results. They may be reported as percent nutrient (%) or parts per million (ppm), or, on rare occasions, on a dry-weight basis. (Most animal waste is measured on a wet-weight [i.e., as-is] basis.) The phosphorus and potassium may be reported on an elemental basis (P and K) rather than the phosphate ( $P_2O_5$ ) and potash ( $K_2O$ ) basis, which is typical of fertilizers. You will need to convert your animal waste test results into the proper fertilizer units for calculating your animal waste application rate.

Animal waste is an excellent fertilizer if it is spread uniformly on a field and at the proper rate. A pound of animal waste phosphate or potash has a nutrient value equivalent to that of commercial fertilizer. Although it has a value as a fertilizer, typically 50 to 80% of the total nitrogen applied is available to crops.

**The plan copy for the operator could include identified sections to store soil and manure, litter and process waste test reports, field application records, crop yield records, and other records related to the plan**