


SIGN BRIDGE HORIZONTAL SPAN INSPECTION SHEET

Project Name: _____ Date: _____

Contract No: _____

Structure No.: _____

Inspector: _____



Note: For information not shown (dimensions, member sizes, etc...) see TM606 through TM612 or TM614 through TM620. Fill in entries T_1 , T_2 , B_1 , B_2 , X_1 , X_2 , W_1 , W_2 , Y_1 , Y_2 , Z_1 , and Z_2 by measuring the centerline distance between the outside bolt holes. T_1 = Span distance for left top chord between outside of chord plates, T_2 = Span distance for right top chord between outside of chord plates, B_1 = Span distance for left bottom chord between outside of chord plates, B_2 = Span distance for right bottom chord between outside of chord plates, X_1 , X_2 , W_1 , W_2 , Y_1 , Y_2 , Z_1 , and Z_2 = the distance from the face of the chord plate to the centerline of the outside bolt holes.

Send this completed form to the Project Manager for field verification of the placement of the vertical end posts.