

Oregon Trucking Online (TOL) External Applications User Manual

January 29, 2026



Commerce and Compliance Division

Table of Contents

How to Access the Applications.....	3
Oregon Trucking Online Citation Reports.....	3
Oregon Trucking Online Web Enforcer.....	5
OSCAR for Enforcement Agencies	7
Change Password	10
Forgot Your Password?	11

How to Access the Applications

Use the links below to access these Oregon Trucking Online (TOL) external applications.

- [Citation Reports.](#)
- [Web Enforcer.](#)
- [OSCAR for Enforcement Agencies.](#)

For questions or assistance, please email [CCD OSCAR and Web Enforcer Administration](#). We will respond to your message within 1 to 2 business days.

Oregon Trucking Online Citation Reports


1. Navigate to [Citations Reports Login](#) web page.

The screenshot shows the 'Oregon Trucking Online Citation Reports' login page. At the top, there's a header with the Oregon Department of Transportation logo and the title 'Oregon Trucking Online Citation Reports'. Below the header, there's a navigation bar with 'Login' and 'Forgot Password' links. The main content area is titled 'Login to Citations' and includes instructions: 'Always logout!' and 'Nobody from ODOT will ask you for your Password.' There are two input fields: 'Login Name' and 'Password', followed by a 'Log In' button. Below the button is a link for 'Forgot your Password?'. At the bottom, there's a footer with four columns of links: 'Social Media' (Facebook, Instagram, Flickr, YouTube), 'Contact Us' (Commerce and Compliance Division (CCD), 455 AIRPORT RD SE, BLDG. A, SALEM, OR 97301 USA, Media Contacts, Agency Directory, Ask ODOT, Contact DMV), 'Links' (TOL Enhancement Project, TOL System Requirements, TripCheck (24/7 travel info), Sign Up for GovDelivery Email Updates, Accessibility at ODOT, Nondiscrimination and Equal Access, Public Records), and 'About Oregon' (Oregon.gov, State Employee Search, Agencies Listing, Accessibility, Privacy Policy, Supported Browsers). There is also a 'Back to Top' link.

2. On the login page, enter your Login Name and Password. Click the Log In button.
 - If you have forgotten your password, you can click the Forgot Password tab in the top navigation bar or the Forgot Your Password? link under the log in button. Navigate to the [Forgot Your Password](#) section if this manual for a full walkthrough.
3. Once logged in, you can choose from a list of citation data.

The screenshot shows the 'Oregon Trucking Online Citation Reports' Citation Data page. At the top, there's a header with the Oregon Department of Transportation logo and the title 'Oregon Trucking Online Citation Reports'. Below the header, there's a navigation bar with 'Select Options', 'Change Password', and 'Logout' links. The main content area is titled 'Citation Data' and includes instructions: 'Click below to access a listing of citation data:'. There is a list of links for various justice courts: 'Clackamas County Justice Court', 'Columbia County Justice Court -Vernona', 'Deschutes County Justice Court-Redmond', 'Harney County Justice Court -Burns Junction', 'Hood River County Cascade Locks Court', 'Jackson County Southern Oregon Court', 'Linn County Justice Court', 'Malheur County Ontario Court', 'Marion County Woodburn Court', 'Tillamook County Tillamook Justice Court', and 'Umatilla County Umatilla Justice Court'. At the bottom, there's a footer with four columns of links: 'Social Media' (Facebook, Instagram, Flickr, YouTube), 'Contact Us' (Commerce and Compliance Division (CCD), 455 AIRPORT RD SE, BLDG. A, SALEM, OR 97301 USA, Media Contacts, Agency Directory, Ask ODOT, Contact DMV), 'Links' (TOL Enhancement Project, TOL System Requirements, TripCheck (24/7 travel info), Sign Up for GovDelivery Email Updates, Accessibility at ODOT, Nondiscrimination and Equal Access, Public Records), and 'About Oregon' (Oregon.gov, State Employee Search, Agencies Listing, Accessibility, Privacy Policy, Supported Browsers). There is also a 'Back to Top' link.

4. Click the link from which you want to view citation data, you will be directed to the following page.



Report	Size (bytes)	Date Created
HARNE289.TXT	0	2025-11-20 02:14:42
HARNE284.TXT	0	2025-11-20 02:14:42
HARNE290.TXT	1089	2025-11-20 02:14:41
HARNE295.TXT	2166	2025-11-20 02:14:41
HARNE292.TXT	0	2025-11-20 02:14:41
HARNE290.TXT	2245	2025-11-20 02:14:41
HARNE293.TXT	0	2025-11-20 02:14:41
HARNE281.TXT	0	2025-11-20 02:14:41
HARNE288.TXT	1096	2025-11-20 02:14:41
HARNE287.TXT	0	2025-11-20 02:14:41
HARNE282.TXT	2218	2025-11-20 02:14:41
HARNE286.TXT	0	2025-11-20 02:14:41
HARNE285.TXT	0	2025-11-20 02:14:41
HARNE259.TXT	0	2025-11-20 02:14:41
HARNE271.TXT	0	2025-11-20 02:14:41
HARNE284.TXT	0	2025-11-20 02:14:41
HARNE283.TXT	0	2025-11-20 02:14:41
HARNE281.TXT	5637	2025-11-20 02:14:41
HARNE280.TXT	0	2025-11-20 02:14:41
HARNE279.TXT	0	2025-11-20 02:14:41

5. Here you will find a table that shows the reports, file size in bytes, and the date the citation report was created.
 - To view this file on the web, you can click the link.
 - To save this file, click on the file and select save link as and select which option you would like from the file type dropdown. Choose where you want to save the file and click the save button.
6. If you would like to change your password when logged in, follow the instructions in the [Change Your Password](#) section of this manual.

This concludes the Oregon Trucking Online Citation Reports section of this manual.

Oregon Trucking Online Web Enforcer

1. Navigate to [Web Enforcer Login](#) web page.

The screenshot shows the 'Oregon Trucking Online Web Enforcer' login page. At the top, there's a header with the Oregon Department of Transportation logo and the title 'Oregon Trucking Online Web Enforcer'. Below the header, there's a navigation bar with 'Login' and 'Forgot Your Password' links. The main content area is titled 'Log Into Web Enforcer' and includes instructions: 'Always log out of your account when finished.' and 'No one from ODOT will ask you for your password.' There are input fields for 'User Name' and 'Password', followed by a 'Log In' button. Below the button are links for 'Forgot Your Password?' and 'For Enforcer help, Email'. At the bottom, there's a footer with four columns of links: 'Social Media' (Facebook, Instagram, Flickr, YouTube), 'Contact Us' (Commerce and Compliance Division, 455 Airport Rd SE, Bldg. A, Salem, OR 97301 USA, Media Contacts, Agency Directory, Ask ODOT, Contact DMV), 'Links' (TOL Enhancement Project, TOL System Requirements, TripCheck (24/7 travel info), Sign Up for GovDelivery Email Updates, Accessibility at ODOT, Nondiscrimination and Equal Access, Public Records), and 'About Oregon' (Oregon.gov, State Employee Search, Agencies Listing, Accessibility, Privacy Policy, Supported Browsers). A 'Back to Top' link is also present.

2. On the login page, enter your User Name and Password. Click the Log In button.
 - If you have forgotten your password, you can click the Forgot Password tab in the top navigation bar or the Forgot Your Password? link under the log in button. Navigate to the [Forgot Your Password](#) section of this manual for a full walkthrough.
3. Once logged in, you will find several options along the top navigation bar.
 - Find Weighing, Insert Weighing, OSCAR, Change Password and Logout.
4. If you click on find weighing, you will see a page that allows you to retrieve a list of previously added weighings from this site.
 - You have the option to select the day the weighing was added in TOL Enforcer, the location of the scale and the plate and state combination.
 - This transaction allows you to see only those weighings added through Web Enforcer. To view all other weighings you can use [OSCAR for Enforcement Agencies](#).

The screenshot shows the 'Find Weighing' page in the Oregon Trucking Online Web Enforcer. The header is the same as the login page. The navigation bar now includes 'Find Weighing', 'Insert Weighing', 'OSCAR', 'Change Password', and 'Logout'. The main content area is titled 'Find Weighing' and includes instructions: 'Retrieve a list of previous weighings to make updates.' and 'Enter a date and click the submit button to view all records. Use the optional filters below to refine your search.' There are input fields for 'The Day' (with a calendar icon), 'Location / Scale' (with a dropdown arrow), and 'Plate State'. A 'Submit' button is at the bottom. The footer is the same as the login page.

- If you click on the Insert Weighing tab, you can manually add a weighing by entering a date, selecting a location or scale from the dropdown, and adding the plate and state combination. Click submit to go to the next page.

The screenshot shows the 'Oregon Trucking Online Web Enforcer' interface. At the top, there's a navigation bar with links: 'Find Weighing', 'Insert Weighing', 'OSCAR', 'Change Password', and 'Logout'. Below this is a header 'Edit Weighing by Date or Scale Number or Base Plate/State'. The form is divided into several sections:

- Date and Time:** 01/27/2026 02:55:22 PM
- Time Zone:** PT (selected), MT
- Event:** Weigh (dropdown)
- Plate State:** YAJY955OR
- Account Number:** 019186
- Carrier Name:** PREMIER AG INC
- Vehicle:** Tractor + Semi Trailer (dropdown)
- Number of Axles:** 5
- Unit Number:** 96
- Year:** 1996
- Make:** PTRB
- Registration Status:** R
- File Status:** A
- Tax Status:** X
- Weight Permit:** (empty)
- ISS:** 67
- Solo:** 460
- Combination 1:** 1055
- Combination 2:** 800
- Combination 3:** 0
- Combination 4:** 1055
- Commodity:** Wood Byproducts (dropdown)
- Placard Number:** (empty)
- Weights:** A vertical list of 12 input fields, each with '0' entered. The last one is labeled 'Gross'.

At the bottom, there's a footer with 'Garry Pullen' and 'Scale: 201 - Philomath'. Two buttons are visible: 'Update This Weighing' (blue) and 'Cancel' (grey).

- On this page, you will see several pieces of data that are auto filled based on the plate and state combination you entered. You can enter the weights for this vehicle on the right side of the screen. You can also add a commodity and/or a placard number at the bottom of the screen. To add this weighing, you can click the Insert this Weighing button. You can also cancel this weighing by clicking the Cancel button.
- Click on the OSCAR tab on the top navigation bar to search for weighings, citations and warnings. To see the full walkthrough of using OSCAR, navigate to the [OSCAR for Enforcement Agencies](#) section of this manual.

This concludes the Web Enforcer section of this manual.

OSCAR for Enforcement Agencies

1. Navigate to [OSCAR for Enforcement Agencies Login](#) web page.

The screenshot shows the login page for the OSCAR for Enforcement Agencies system. At the top, there is a header with the Oregon Department of Transportation logo and the text "OSCAR for Enforcement Agencies". Below the header, there is a navigation bar with links for "Login" and "Forgot Your Password?". The main content area is titled "Log Into OSCAR for Enforcement Agencies" and contains a login form with fields for "User Name" and "Password". Below the form is a "Log In" button and a link for "Forgot Your Password?". A footer section contains links for "Social Media", "Contact Us", "Links", and "About Oregon".

2. On the login page, enter your User Name and Password. Click the Log In button.
 - If you have forgotten your password, you can click the Forgot Password tab in the top navigation bar or the Forgot Your Password? link under the log in button. Navigate to the [Forgot Your Password](#) section of this manual for a full walkthrough.
3. Click on Select Options to search for weighings, citations and warnings. You can filter these results with start and end date and either with an Oregon Account Number or with a base plate and state or province combination.

The screenshot shows the "OSCAR: Selection Options" page. At the top, there is a header with the Oregon Department of Transportation logo and the text "OSCAR for Enforcement Agencies". Below the header, there is a navigation bar with links for "Select Options", "Change Password", "Logout", and "WIM Codes". The main content area is titled "OSCAR: Selection Options" and contains a warning message. Below the warning, there are two sections for selecting options. The first section is "Retrieve a carrier's records for a date range" and includes fields for "Start" and "End" dates, a "Carrier's Oregon Account Number" field, and a "Choose either" dropdown. The second section is "Retrieve a truck's records by base plate" and includes a "Base Plate" field, a "State or Province" dropdown, and a "Choose record types to retrieve" section with checkboxes for "Weighings", "Citations", and "Warnings". There are "Submit" and "Reset" buttons at the bottom of the form. A footer section contains links for "Social Media", "Contact Us", "Links", and "About Oregon".

4. Click submit and you will see the results for the specific information you added.
 - The screenshot below shows citation, weighing and warning results from 10/01/2025 to 11/19/2025.

The screenshot displays the 'OSCAR for Enforcement Agencies' interface. At the top, there's a navigation bar with links: 'Select Options', 'Change Password', 'Logout', and 'WIM Codes'. The main heading is 'OSCAR: Selection Results'. Below this, it shows 'Citation Information from 10/01/2025 to 11/19/2025 for'. A dropdown menu shows '25' entries per page. A table lists citation data with columns: Date-Time, Day, Time Zone, Scale, Scale Location, Citation, Voided, Violation, Plate, State, Driver Name, and Authority Number. The first entry is for 23-Oct-25 at 06:50:00AM, Thursday, PT, at scale 1604 Juniper Butte S, with citation N and violation ORS 818.400 (1) (a). Below the citation table, it shows 'Warning Information from 10/01/2025 to 11/19/2025 for' with a similar table structure. The first warning entry is for 03-Nov-25 at 09:32:00PM, Monday, PT, at Umatilla POE, scale 3006, IN, ORS 818.020, with a violation 'Exceeding maximum weight limits' and a comment about axle weight overload. At the bottom, there are links for 'Back to Selection Options Screen' and 'Help with Vehicle Codes, Commodity Types, or Scale Locations', along with social media and contact information.

5. At the bottom left of the screen there are two links: Back to Selection Options Screen and Help with Vehicle Codes, Commodity Types, or Scale Locations.
 - Back to Selection Options Screen will take you back to the page seen in step 3.
 - Help with Vehicle Codes, Commodity Types, or Scale Locations will bring you to a page with descriptions for each of these codes.
 - You can also print these lists by clicking Print and then ctrl+p or download a spreadsheet by clicking Excel.

The screenshot shows the 'Code Explanations' section of the OSCAR application. It has two main parts: 'Vehicle Types' and 'Commodity Codes'. Each part has a table with 'Code' and 'Description' columns. The 'Vehicle Types' table lists codes 3 through 8 with descriptions like 'Tractor + Semi Trailer', 'Solo Vehicle', 'Log Truck + Pole Trailer', 'Truck + Trailer', 'Doubles', 'Triples', 'Dromedary', and 'Other'. The 'Commodity Codes' table lists codes 0 through 6 with descriptions like 'Empty', 'Logs, Poles, Piling', 'Other', 'Lumber Products', 'Rock Products', 'Machinery', and 'Wood By-Products'. Both tables have 'Print' and 'Excel' buttons above them. The interface also includes the same top navigation bar as the previous screenshot.

6. Click Logout. You will be logged out and taken to the login screen seen in Step 1.

- Click WIM Codes. This option will download a PDF version of Report and Bypass Reason Codes.

REPORT REASON CATEGORIES	REASON CODE	DESCRIPTION/MEANING
WIM MANIPULATION	OMANIP	WIM Manipulation Error (i.e.: off-scale detector, truck oscillation, braking, etc.)
	OSPCBG	Excessive Speed change (Acceleration or Deceleration)
	O2SLOW	Vehicle travelling too slow
	O2CLOS	Vehicle too close in front or behind
	ONLUMAX	Invalid number of axes
WEIGHT	WAFRNT	Overweight front axle
	WAXn	Overweight single axle (where n is the ordinal position of the overweight axle)
	WTAn	Overweight tandem axle (where n is the ordinal position of the overweight tandem axle)
	WTRIn	Overweight tridem (where n is the ordinal position of the overweight tridem axle)
	WSTRIn	Overweight short tridem fitting into tandem definition (where n is the ordinal position of the overweight tridem axle)
	WCNOP	Overweight combination, without permit
	WCPSTD	Overweight combination, with permit, violating statute weights
	WCPEXT	Overweight combination, with permit, violating permit weights
OVERHEIGHT	HOVER	Over-Height
SAFETY	SFLAG	Safety FLAG set
	STHRES	Safety Inspection Threshold flag
DATABASE	ONOTRN	A/I does not find transponder
	ONOTDB	Transponder number not found within database
	OCRIER	Invalid carrier authority
	OPLATE	Invalid plate not found within database
	DBCLSV	Blank/Invalid Carrier Service Code → (1, 2, 3, 4, or A, B, C, D to bypass) v is the Carrier Level Of Status **See Note 1
	DBSFTv	Blank or "U" Safety Rating Code → (will cause report w/ this code) v is the Safety Rating value found **See Note 2
	DBSRCv	Report Inspection Status Code → (an "H" will cause report w/ this code) v is the Safety Risk value found **See Note 3
OTHER	XVNUM	Computer-to-Computer "Packet Collision" or Packet numbering fault
	ORWIND	WIM Independent Mode
	NETERR	Network Error
BYPASS REASONS		
	OBWIND	WIM independent mode (set to "Legal weight")
	OBYPAS	Passes all weight/credential checks
	WBLOWM	Passes extended weight/credential checks
	WBEMPT	Below empty weight threshold (note: should apply to In-ramp only - currently)
	OBNTSL	Vehicle not in sort class or lane

*Note 1 The value "Carrier Level Of Status" is interpreted as: ** Note 2 The value "Safety Rating" is interpreted as: ***Note 3 The value "Safety Risk" is the


This concludes the OSCAR for Enforcement Agencies section of this manual.

Change Password

1. From any of the applications, you can always change your password by navigating to the top menu bar and clicking Change Password.

The screenshot shows the 'Oregon Trucking Online Web Enforcer' interface. At the top, there's a navigation bar with links: Find Weighing, Insert Weighing, OSCAR, Change Password, and Logout. Below this, a message states: 'A password is case-sensitive, must be a minimum of 14 characters long and must contain at least one:' followed by a list of requirements: Special character from a list (@ \$ % ! ^ * () + ? < >), Number, and Capital letter. A link for 'Guidelines for creating effective Passwords' is provided. The form has two password fields: 'New Password' and 'Confirm New Password', each with a toggle for visibility. Below these is the 'Change Your Security Question' section, which includes instructions and requirements for the question and answer. It features two text input fields for 'Security Question' and 'Answer' (with a 30-character limit), and a 'Submit Change(s)' button. The footer contains four columns of links: Social Media (Facebook, Instagram, Flickr, YouTube), Contact Us (Commerce and Compliance Division, Media Contacts, Agency Directory, Ask ODOT, Contact DMV), Links (TOI Enhancement Project, TOI System Requirements, TripCheck, Sign Up for GovDelivery Email Updates, Accessibility at ODOT, Nondiscrimination and Equal Access, Public Records), and About Oregon (Oregon.gov, State Employee Search, Agencies Listing, Accessibility, Privacy Policy, Supported Browsers).

2. Enter a new password according to the requirements listed on the page. Confirm the password you just entered.
 - If you are unsure how to create an effective password, you can click the Guidelines for creating effective Passwords link.
3. Enter your security question and answer. It is very important that you create a security question that is memorable. Both the question and answer are case sensitive.
4. To submit these changes, click the Submit Change(s) button.
5. You will receive a confirmation message and a confirmation email. The confirmation email shown below is from the forgot password for OSCAR for Enforcement Agencies. However, all confirmation emails will have the same format as shown below.



You have successfully changed your password and security question!

Forgot Your Password?

1. From any of the application log in pages, click Forgot your Password? or navigate to the top menu bar and click Forgot Password. You will be redirected to the following page.

Forgot your Password?

We can help you, if you enter your login name [Submit](#)

Social Media Like us on Facebook Follow us on Instagram See us on Flickr Watch us on Youtube Back to Top	Contact Us Commerce and Compliance Division (CCD) 455 AIRPORT RD SE, BLDG. A SALEM, OR 97301 USA Media Contacts Agency Directory Ask ODOT Contact DMV	Links TOL Enhancement Project TOL System Requirements TripCheck (24/7 travel info) Sign Up for GovDelivery Email Updates Accessibility at ODOT Nondiscrimination and Equal Access Public Records	About Oregon Oregon.gov State Employee Search Agencies Listing Accessibility Privacy Policy Supported Browsers
--	---	--	---

2. Enter your login name and click submit.
3. Enter your security answer. Your answer is case sensitive!

Answer Your Security Question


The answer is case sensitive so enter it **exactly** as you did when your account was first created. (Case matters!)

Security Question First Car (make and model)
Answer [Submit Answer](#)

Social Media Like us on Facebook Follow us on Instagram See us on Flickr Watch us on Youtube Back to Top	Contact Us Commerce and Compliance Division (CCD) 455 Airport Rd SE, Bldg. A Salem, OR 97301 USA Media Contacts Agency Directory Ask ODOT Contact DMV	Links TOL Enhancement Project TOL System Requirements TripCheck (24/7 travel info) Sign Up for GovDelivery Email Updates Accessibility at ODOT Nondiscrimination and Equal Access Public Records	About Oregon Oregon.gov State Employee Search Agencies Listing Accessibility Privacy Policy Supported Browsers
--	---	--	---

Note: This individual has their security question as First Car (make and model), your security question will reflect the one you chose.

4. If you successfully entered the security answer, you will get a confirmation message and be sent an email with a link to reset your password. **Important:** This link will expire after 15 minutes!



5. If you click this link, you will be redirected to a page to reset your password.

Oregon Department of Transportation

Oregon Trucking Online Web Enforcer

Login Forgot Your Password

Reset Your Password

A password is case-sensitive, must be a minimum of 14 characters long and must contain at least one:

- Special character from this list: @ \$ % ! ^ * () + ? < >
- Number
- Capital letter.

New Password

Confirm New Password

[Submit](#)

Social Media
[Like us on Facebook](#)
[Follow us on Instagram](#)
[See us on Flickr](#)
[Watch us on Youtube](#)


Contact Us
[Commerce and Compliance Division \(CCD\)](#)
455 Airport Rd SE, Bldg. A
Salem, OR 97301 USA
[Media Contacts](#)
[Agency Directory](#)
[Ask CCD](#)
[Contact DMV](#)

Links
[TOL Enhancement Project](#)
[TOL System Requirements](#)
[TripCheck \(24/7 travel info\)](#)
[Sign Up for GovDelivery Email Updates](#)
[Accessibility at CCD](#)
[Nondiscrimination and Equal Access](#)
[Public Records](#)

About Oregon
[Oregon.gov](#)
[State Employee Search](#)
[Agencies Listing](#)
[Accessibility](#)
[Privacy Policy](#)
[Supported Browsers](#)

[Back to Top](#)

6. Enter and confirm your new password and click submit. You will get a confirmation message and a confirmation email. The confirmation email below is from the forgot password for Oregon Trucking Online Web Enforcer. However, all confirmation emails will have the same format as shown below.



**You have
successfully reset
your password!**