

PLUGGING RECORD

STATE DEPT. OF GEOLOGY AND MINERAL INDU. RIES

The owner or operator of any oil or gas well or stratigraphic hole shall file this form with the Director of the State of Oregon Department of Geology and Mineral Industries setting forth in detail the method used in plugging such well. The form must be filed within twenty (20) days after plugging for oil and gas wells, or within sixty (60) days for stratigraphic holes.

Rule L of rules and regulations adopted pursuant to ORS 520.095 (1) (13) (Chapter 667 OL 1953)

Operator Ross R. Mitchell & Associates Field Dallas area
Pool _____
County Polk

ADDRESS ALL CORRESPONDENCE CONCERNING THIS FORM TO:

Street 3898 - 7th Avenue, N.E. City Salem State Oregon
Lease Name Bliven Well No. 3 Sec. 10 T. 8 S R. 5 W
Date well was plugged July 13 1960.

Was the well filled with mud laden fluid, according to regulations of the Board of the State of Oregon Department of Geology and Mineral Industries? Yes

How was the mud applied? Pump Were plugs used? Cement If so, show all shoulders left for casing, depth of each, and size of casing, size and kind of plugs used, and depths placed. Also amount of cement and rock. Use additional sheets if necessary.

**6-5/8" casing cemented at 50 feet with six sacks of construction cement.
6" hole drilled to 580 feet T.D.**

(For plugging details see other side.)

Was notice given, before plugging, to all available adjoining lease and land owners?

Ross R. Mitchell & Associates
(Operator)
By Ross R. Mitchell
AFFIDAVIT

State of Oregon
County of Clackamas

I, Ross R. Mitchell, being duly sworn, say that I have knowledge of the facts stated herein, that they are true and correct, and that I am authorized to make this report.

Subscribed and sworn to before me this 9th day of Aug. 1960

Notary public in and for Perry J. Board

My commission expires Jan. 12, 1961.

Plugging details

1. Took valves off casing.
2. Bailed hole dry.
3. Filled hole with mud.
4. Cement plug (60-40') with 5 sacks of construction cement. Placed cement with bailer.
5. Put a 10-foot cement plug at the top of the 6-5/8" casing. Filled hole with mud between plugs.
6. Cut off casing 2 feet below the ground surface and welded a steel plate over the casing stub.