

STATE OF OREGON  
DEPARTMENT OF GEOLOGY AND MINERAL INDUSTRIES  
1069 State Office Building                      Portland 1, Oregon

*6-11-83 243*

HISTORY OF OIL OR GAS WELL

(Submit in duplicate)

In compliance with rules and regulations adopted pursuant to ORS 520.095 (Chapter 667 OL 1953)

Operator REICHHOLD ENERGY CORPORATION

FieldPittsburg

Well No. Investment Management 21-2Q Sec. 20

, T. 6N

R.

4W

W. B. & M.

Signed *Godd Thomas*

Date September 22, 1983

Title Field Operations, Supervisor  
(President, Secretary or Agent)

It is of the greatest importance to have a complete history of the well. Use this form in reporting the history of all important operations at the well, together with the dates thereof, prior to the first production. Include in your report such information as size of hole drilled to cementing or landing depth of casings, number of sacks of cement used in the plugging, number of sacks or number of feet of cement drilled out of casing, depth at which cement plugs started, and depth at which hard cement encountered. If the well was dynamited, give date, size, position and number of shots. If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.

Date	If plugs or bridges were put in to test for water, state kind of material used, position and results of pumping or bailing.
9-15-83	Spudded well and drilling 12 1/4" hole
9-16-83	Drilling 12 1/4" hole to 477'. Ran 12 jts. of 8 5/8" casing to a measured depth of 478.11 and cemented with 205 sks. class "G" cement.
9-17-83	Test BOP's with Bill King and drilling float
9-18-83	Drilling cement and 7 7/8" open hole 630'
9-19-83	Drilling 1530'
9-20-83	Drilling TD well at 2505'
9-21-83	Logging with Welox, Abandon well. Bottom plug set from 1380' to 950' with 158 sks. class "G" cement. Top plug set from 700' to 377' with 120 sks. class "G" cement.
9-22-83	Go in hole and tag plug at 376' with Bill King witnessing

RECEIVED  
101 1983  
DEPT. OF GEOLOGY